



Ref #	Part #	Description	Context Note	Foot Note
1	NSP	ASSY, Enclosure		
2	NSP	BACK PANEL		
3	195667GS	TRANSFER SWITCH, 100A		
4	-----	HHS, Trilobular, #10 - 32 x 1/2	Purchase locally	
5	198725GS	BREAKER Circuit		
6	-----	WASHER, Ext. Tooth, #10	Purchase locally	
7	-----	HHS, Trilobular, #6- 32 x 3/8	Purchase locally	
8	193664GS	INSULATION, Dead Front		
9	197279GS	CONTROL, Board		
10	197979GS	SPACER, PCB Board, 1/2		
11	198722GS	BREAKER Circuit		
12	198721GS	BREAKER Circuit		
13	198723GS	BREAKER Circuit		
14	NSP	BUS, Double Rw Brkr Mntng		
15	204511GS	COVER, Circuit Board		
16	B4857GS	FUSE		
17	192151GS	FUSE HOLDER		
18	NSP	SPACER		
19	NSP	BAR, Neutral Connection		
20	B4986GS	DECAL, Ground		
21	NSP	GROUND BAR		
22	-----	SCREW, Trilobular, #10 - 32 x 3/4	Purchase locally	
23	205108GS	DECAL, 100A, ATS		
24	204433GS	SPACER		
25	190992GS	DECAL, Warning Shock		
26	190984GS	DECAL, Fuse		
27	192597GS	DECAL, Sensing, Utility		
28	-----	WASHER, Lock 1/4	Purchase locally	
29	-----	NUT, 1/4 - 20	Purchase locally	
30	193159GS	DECAL, Reinstall		
31	-----	PPHMS, 6-32x 3/8	Purchase locally	
32	-----	HHS, Trilobular, #8- 32 x 3/8	Purchase locally	
33	-----	WASHER, Lock #6	Purchase locally	
34	204431GS	WIRE - R		
35	204432GS	WIRE - R		
36	202841GS	SUPPORT, Locking, Crct Brd		
37	196355GS	DECAL, CT Warning		
38	197198GS	DECAL, Wire Circuits		
39	197294GS	DECAL, Contacts Rating		
	202267GS	MANUAL, Operator's	Parts Not Illustrated	
	195728GS	CURRENT TRANSFORMER	Parts Not Illustrated	