

Parts List – L100-300 Chain Hoist (3.0 Ton)

Parts listed under each assembly are parts that make up that assembly. Sold as an assembly only.

Index No.	Part No.	Description	Size	Qty
1	L100-300-1	Top Hook Assembly		1
		Top Hook		1
		Safety Latch		1
		Double Spring		1
		Socket Head Cap Screw	M5x30	1
		Lock Nut	M5	1
		Top Hook Holder		1
		Rivet	10x32	2
2	L100-300-2	Safety Latch Assembly		2
		Safety Latch		2
		Double Spring		2
		Socket Head Cap Screw	M5x30	2
		Lock Nut	M5	2
3	L100-300-3	Top Hook Shaft		1
4	L100-100-4	Split Pin	2.5x20 mm	1
5	L100-300-5	Bottom Hook Assembly		1
		Bottom Hook		1
		Safety Latch		1
		Double Spring		1
		Socket Head Cap Screw	M5x30	1
		Lock Nut	M5	1
		Idle Shaft		1
		Idle Sheave		1
		Socket Head Cap Screw	M8x25	2
		Lock Nut	M8	2
		Lock Nut	M12	2
		Lock Washer	M12	2
		Bottom Hook Holder		1
8	L100-300-8	Hand Wheel Cover Assembly		1
		Hand Wheel Cover		1
		Hand Chain Guide		2
8A	L100-50-8A	Warning Label		1
9	L100-50-9	Positional Collar		1
	L100-50-9-1	Wheel Stopper (Available from 2010-02-01)	M8	1
10	L100-50-10	Pin		1
	L100-50-10-1	Wheel Washer (Available from 2010-02-01)		1
11	L100-50-11	Split Pin (Cancelled from 2010-02-01)	1.5x15 mm	1
12	L100-100-12	Hand Chain – specify length	5x25 mm	1
13	L100-100-13	Hand Chain Connecting Link		1
14	L100-300-14	Hand Chain Wheel		1
	L100-300-14-1	Hand Chain Wheel (Available from 2010-02-01)		1
14L-300	L100-300WO-14L	Overload Limiter Assembly (used on overload protection model)		1
	L100-300WO-14-1L	Overload Limiter Assembly (used on overload protection model) (Available from 2010-02-01)		1
		Overload Limiter Knob		1
		Brake Disc		2
		Hand Chain Wheel		1
		Bushing in Hand Chain Wheel		1
		Disc Spring Plate		1
		Disc Spring		1
		Disc Spring Stopper		1
		Lock Nut		1
15	L100-100-15	Snap Ring	10 mm	2
16	L100-100-16	Pawl		2
17	L100-100-17	Pawl Spring		2

Parts List: L100-300 Chain Hoist (3.0 Ton)

18.....	L100-100-18	Ratchet Disc Assembly	1
.....	L100-300-18-1	Ratchet Disc Assembly (<i>Available from 2010-02-01</i>)	1
.....		Ratchet Disc	1
.....		Ratchet Bushing	1
19.....	L100-100-19	Disc Hub	1
.....	L100-100-19-1	Disc Hub (<i>Available from 2010-02-01</i>)	1
20.....	L100-300-20	Wheel Side Plate Assembly	1
.....	L100-300-20-1	Wheel Side Plate Assembly (<i>Available from 2010-02-01</i>)	1
.....		Wheel Side Plate	1
.....		Stay Bolt	3
.....		Pawl Pin	2
.....		Brake Cover	1
.....		Double Seal Ball Bearing	d30xD55x13 mm 1
21.....	L100-100-21	Double Seal Ball Bearing	d30xD55x13 mm 1
21A.....	L100-100-21	Double Seal Ball Bearing	d30xD55x13 mm 1
21B.....	L100-100-21B	Double Seal Ball Bearing	d10xD30x9 mm 1
22.....	L100-300-22	Gear Side Plate Assembly	1
.....		Gear Side Plate	1
.....		Bushing	2
.....		Double Seal Ball Bearing	d30xD55x13 mm 1
23.....	L100-300-23	Load Gear	1
24.....	L100-300-24	Drive Shaft	1
.....	L100-300-24-1	Drive Shaft (<i>Available from 2010-02-01</i>)	1
25.....	L100-300-25	Gear Case Assembly	1
.....		Gear Case	1
.....		Bushing	2
.....		Double Seal Bearing	d10xD30x9 mm 1
26.....	TS-2361081	Lock Washer	M8 3
26A.....	TS-2361081	Lock Washer	M8 3
27.....	TS-1541031	Lock Nut	M8 3
27A.....	TS-1541031	Lock Nut	M8 3
28.....	L100-100-28	Rivet	3x6 mm 4
29.....	L100-300-29	Name Plate	1
29.....	L100-300WO-29	Name Plate (<i>used on overload protection model</i>)	1
30.....	L100-300-30	Spur Gear Assembly	2
.....		Spur Gear	2
.....		Pinion Gear	2
31.....	L100-300-31	Load Sheave	1
31A.....	L100-50-31A	C-Clip	21 mm 1
31B.....	L100-50-31B	Needle Bearing	14x21x12 mm 1
32.....	L100-300-32	Guide Roller	2
33.....	L100-300-33	Stripper	1
34.....	L100-300-34	Chain Anchor Plate	1
35.....	L100-300-35	Chain Anchor Pin	1
36.....	L100-100-36	Split Pin	2x15 mm 1
37.....	L100-300-37	Load Chain – <i>specify length</i>	7.1x21 mm 1
38.....	L100-300-38	Top Hook Pin	1
39.....	TS-1541031	Lock Nut	M8 1
40.....	TS-1504051	Socket Head Cap Screw	M8x25 2
41.....	TS-1541031	Lock Nut	M8 2
42.....	L100-300-42	Idle Shaft	1
43.....	L100-300-43	Idle Sheave	1
47.....	L100-300-47	Snap Ring	28 mm 1
48.....	L100-300-48	Dust Cover (<i>Available from 2010-02-01</i>)	1

Note: When ordering replacement chain (Index #12, #37), specify length.

L-100 Chain Hoist Parts Breakdown

