



Parts List for 11267 Type 1

Item Number	Part Number	Description	Qty Required
1	000000-00	No Longer Available	1
2	144960-00	SWITCH (ON-OFF)	1
3	000000-00	No Longer Available	1
4	000000-00	No Longer Available	1
5	000000-00	No Longer Available	1
6	000000-00	No Longer Available	1
8	000000-00	No Longer Available	1
9	152122-01	LATCH,BATTERY	1
10	330019-00	SCREW	8
11	330024-00	SCREW	2
14	000000-00	No Longer Available	2
15	000000-00	No Longer Available	1
16	000000-00	No Longer Available	1
19	072412-00	PLUG	3
20	000000-00	No Longer Available	2
21	000000-00	No Longer Available	1
835	000000-00	No Longer Available	1
866	11271	3.6V BATTERY	1
871	000000-00	No Longer Available	1