


120S31 Pump UT-01481 01481-UT 120S31 Pump UT-01481 120S31 Pump - Pump



Ref #	Part #	Description	Qty
1	496031	HANDLE	1
2	81043	NUT- 3/8-16	7
3	83018	WASHER- Lock, 3/8"	11
4	84010	WASHER- Flat, 3/8"	2
5	54361	STUD	2
6	629802	HOUSING- Impeller	1
7	67908	PIN- Coiled spring	1
8	62688	SLINGER	1
9	627131	SEAL ASSEMBLY	1
10	75909	SHIM- Seal (.010")	A/ R
	75910	SHIM- Seal (.015")	A/ R
11	62408	SPACER	1
12	540673	IMPELLER	1
13	62927	GASKET- Large	2
14	629262	PLATE- Wear	1
15	62928	GASKET- Small	1
16	A43971	FILLER PLUG	1
17	18108	GASKET	1
18	A50846	HOUSING- End	1
19	743431	NIPPLE- Suction	1
20	542891	FITTING- Pipe (discharge)	1
21	62315	DECAL- Fill pump	1
22	A43896	USE UP07092	1
23	59910	GASKET	1
24	80085	SCREW- Hex hd, 5/16-18 x 1"	6
25	A62917	SKID ASSEMBLY	2
26	25407	SPRING	3
	85025	RIVET (Not shown)	3
27	81018	NUT- Hex, 5/16-18	6
28	83003	WASHER- Lock, 5/16"	10
29	84046	WASHER- Flat, 5/16"	6
30	626621A	ANGLE- Base (right)	1
31	81162	NUT- Hex, 5/16-18	8
32	83002	WASHER- Lock 5/16"	4
33	80695	SCREW- Hex, 5/16-18 x 3/4"	4
34	421211A	BRACKET- Engine mounting	1
35	80288	SCREW- Hex, 5/16-18 x 13/4"	4
36	30679	STUD	4
37	800973	BOLT- 3/8-16 x 1 1/2"	2
38	49266	TACK- Metal	4
39	54661	PLATE- Warning	1
40	626611A	ANGLE- Base (Left)	1

Ref #	Part #	Description	Qty
	30129	STRAINER	1
	624501	HOLDER- Spanner wrench (Not shown)	1
	20024B	WRENCH- Spanner (Not shown)	1
	48481	SUCKER- Puddle	1
	627132	SEAL- (For Solvents)	1
	A48374	PUMP OVERHAUL KIT	1
	23475	PAINT- Red, spray (12 oz. can)	1