


120TP31C Trash Pump UT-01537-C 01537-C-UT 120TP31C Trash Pump UT-01537-C 120TP31C Trash
Pump - Pump & Frame



Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty
1	81162	NUT - Hex (5/16-18)	20
2	83002	WASHER - Lock (5/16)	20
3	20024B	WRENCH - Spanner	1
4	80085	SCREW - Hex hd. (5/16-18 x 1)	4
5		ENGINE	1
6	421211A	BRACKET - Pump engine	1
7	80044	SCREW - Hex hd. (1/4-20 x 1/2)	1
8	84020	WASHER - Flat (1/4")	1
9	A07952	ROLL CAGE	1
10	07958	CHANNEL, ENGINE	2
11	49367	ISOLATOR VIBRATION	6
12	624501	BRACKET - Spanner Wrench	1
13	A47651	BODY - Pump	1
14	82381	SCREW - Hex hd. (5/16-18 x 1 3/4")	1
15	62688	SLINGER	1
16	80288	SCREW - Hex hd. (5/16-18 x 1 3/4")	4
17	548662A	HANDLE - Disconnect	4
18	62677	SHIM - Impeller (.032")	2
19	62676	SHIM (.015")	2
20	626552	IMPELLER	1
21	514582	HOUSING - Impeller	1
22	62675	SHIM - Impeller (.010")	2
23	54398	STUD - Handle	4
24	54397	PIVOT - Handle	4
25	A43404A	HOUSING - End	1
26	83020	WASHER - Lock (1/2")	2
27	80272	SCREW - Cap hex hd. (1/2-13 x 1 1/4")	2
28	81111	NUT - Hex (10-32)	2
29	626576A	FITTING - Pump Section	1
30	62669	VALVE - Plate	1
31	62667	VALVE - Flapper	1
32	62668	VALVE - Plate	1
	08970	DECAL - Fill Pump	1
	08971	DECAL - Warning	1
33	542891	NIPPLE	1

Ref #	Part #	Description	Qty
34	80032	SCREW (10-32 x 1/2")	2
35	62367	GASKET - Pump body	1
36	A43971	FILLER PLUG	1
37	18108	GASKET - Wing nut	1
38	A43896	USE UP07092	1
39	59910	GASKET - Drain & Filler cap	1
40	74454A	STRAINER - Suction	1
41	62363A	GASKET - End plate	1
42	62665A	GASKET - Impeller housing	1
43	62716	NUT - Impeller	1
44	627131A	SEAL - Shaft	1
45	80402A	SCREW - Hex cap (1/4-20 x 5/8")	3
46	514562	PLATE - Wear	1
47	62772	"O" RING	1
48	80771B	SCREW - Cap hex hd. (3/8-16 x 1 1/4")	4
49	62666	WASHER - Sealing	4
50	532731	STUD, Eye nut	1
51	54193	NUT, Eye	1
52	84032	WASHER-Flat (5/16)	8