



BOSCH

Router

1601 | 0 601 601 034

Table of Content

Spare parts list.....	2
Illustration - Type.....	4

Spare parts list

Item	Part Number	Description	Illustration
1	3 605 108 553	Motor Housing BLUE	1
2	3 604 220 525	Field 115V	1
3	3 604 011 500	Armature 115V	1
4	3 605 500 584	Sealing cap	1
5	3 600 900 506	groove ball bearing	1
6	3 600 034 500	Front Panel	1
7	3 600 133 500	Protective Washer	1
8	3 600 900 503	groove ball bearing	1
9	3 607 200 505	Switch	1
10	3 604 460 555	Power supply cord USA/CDN 2,15m 2 x 0,82mm SJ 18/2	1
11	3 600 390 500	Compression-Gland Fitting	1
12	3 600 703 500	Grommet	1
13	3 601 023 500	Switch Plate	1
15	3 600 210 500	O-Ring	1
17	3 600 492 500	Carbon Brush Holder	1
19	3 601 023 501	fixing plate	1
21	3 608 098 501	Nut	1
22	3 600 499 500	Collet	1
23	3 603 313 500	Union Nut	1
24	3 600 410 500	Spacer	1
25	3 603 429 508	Socket head cap screw	1
26	2 916 680 006	Spring Lock Washer DIN 127-B 5	1
27	3 603 410 502	Socket head cap screw	1
28	3 603 415 536	Socket head cap screw	1
29	3 603 301 500	Hex Nut	1
33	3 605 702 568	Base	1
34	3 603 231 500	Ball Knob	1
35	3 600 190 500	Base Plate	1
36	3 601 119 692	Nameplate	1
37	3 603 440 500	Square-Head Bolt	1
38	3 600 100 500	Washer	1
39	3 603 339 500	Wing Nut	1
40	2 910 011 219	Socket head cap screw DIN 84-BM6x70-5.8	1
41	2 916 030 013	Toothed lock washer DIN 6797-A16,5-FST	1

Spare parts list

Item	Part Number	Description	Illustration
43	2 610 915 162	Screw	1
44	3 601 119 600	Dummy	1
44	3 603 340 500	Socket head cap screw	1
49	1 601 110 449	Nameplate CAUTION	1
50	3 603 344 504	Latch	1
50/2	3 603 231 509	Latch	1
50/3	3 603 410 500	Socket head cap screw	1
50/4	3 604 612 500	Compression Spring	1
650/5	9 601 497 900	Single-Head Eng. Wrench SW 9/16	1
650/6	9 601 497 905	Single-Head Eng. Wrench SW 6	1
733	3 605 702 600	Base Plate	1

Illustration - Type - E

Type 0 601 601 0 .. (0 601 905 1 ..)
 Issue } 93 - 01 1 602 1 .. (0 601 905 2 ..)
 Stand } 1 604 1 .. (0 601 905 4 ..)

