



160TP41A Trash Pump UT-01512 01512-UT 160TP41A Trash Pump UT-01512 160TP41A Trash Pump -
Dolly



Ref #	Part #	Description	Qty
29187	29187	PLUG- Button	1
40802-1	408021	SPACER	1
42427-1	424271	BRACKET	1
42430	42430	LEVER- Control	1
42431	42431	HOSE- Oil supply	1
42436	42436	FITTING	1
42469	42469	PROBE- Pumping	1
42470	42470	DECAL	1
42972	42972	NUT- Conduit	1
42969-1	429691	PLATE- Throttle	1
A-43442	A43442	ENGINE & DECAL	1
43853	43853	HOLDDOWN- Battery	1
43803-11	4380311	CABLE- Battery	1
43803-02	4380302	CABLE- Battery	1
43804	43804	BOLT- Holddown	1
46143	46143	BATTERY	1
46484-A	46484A	PIN- Latch	1
A-46487	A46487	HANDLE	1
A-46492	A46492	DOLLY & FRAME	1
46497	46497	TUBING- Spacer	1
46499	46499	SPRING- Compression	1
46500-A	46500A	SUPPORT- Engine left	1
46502-A	46502A	SUPPORT- Engine right	1
46504	46504	ANGLE- Mounting	1
46598	46598	BRACKET- Aux. oiler	1
46629	46629	DECAL	1
46948	46948	ISOLATOR- Vibration	1
A-46950	A46950	KIT- Battery mounting	1
46951	46951	TUBING- Rubber	1
A-50893-A	A50893A	TANK- Oil	1
50896	50896	DECAL- Oil tank	1
50916	50916	CAP	1
50917	50917	BRACKER- Mounting	1
50918	50918	FITTING- Hose	1
A-53254	A53254	WHEEL & TIRE	1
53349	53349	HEAD- Oil pump	1
53359	53359	CLAMP- Hose (oil)	1
53436	53436	WHEEL	1
53876A	53876A	LABEL- Service instr.	1
66608	66608	HUB- Cap	1
66628	66628	WASHER- Flat	1

Ref #	Part #	Description	Qty
80097-3	800973	SCREW- Cap hex hd. 3/8-16 x 1.500	1
802181	802181	SCREW- Mach. hex (1/4-20)	1
80522	80522	SCREW- Cap hex hd.	1
80579	80579	SCREW- Mach. pan hd. (10-32 x 3/8)	1
80695	80695	SCREW- Mach. hex hd. (5/16-18 x 3/4)	1
81010-1	810101	NUT- Hex (10-32 x 3/8)	1
81018-1	810181	NUT- Hex (5/16 x 18)	1
81043	81043	NUT- Hex (3/8-16)	1
81053	81053	NUT- Hex (1/4-20)	1
81162	81162	NUT- Hex (5/16-18)	1
81218	81218	WASHER- Lock (5/16)	1
81218	81218	WASHER- Lock (5/16)	1
83002	83002	WASHER- Lock (5/16)	1
83009	83009	WASHER- Lock (1/4)	1
83018	83018	WASHER- Lock	1
83030	83030	LOCKWASHER	1
83046	83046	WASHER- Lock	1
84006	84006	WASHER- Flat	1
84010-1	840101	WASHER	1
84032	84032	WASHER	1
840651	840651	WASHER	1
86303	86303	PIN- Cotter	1
86319	86319	PIN- Cotter	1

160TP41A Trash Pump UT-01512 01512-UT 160TP41A Trash Pump UT-01512 160TP41A Trash Pump -
Pump



Ref #	Part #	Description	Qty
18108	18108	GASKET- Wing plug	1
22148	22148	WRENCH- Spanner	1
25672	25672	GASKET- Hose coupling	1
43439-2	434392	IMPELLER	1
43893	43893	SHIM (0.10)	1
43894	43894	SHIM (0.32)	1
43895	43895	SHIM (0.32)	1
A-43896	A43896	USE UP07092	1
46150	46150	SEAL- Shaft	1
46151	46151	NUT- Hex	1
A-47145	A47145	KIT- Impeller	1
47414	47414	DECAL	1
50679-1	506791	WEAR- Plate	1
53189	53189	GASKET- Wear plate	1
53273-1	532731	NUT- Eye stud	1
53341-2	533412	CAP- Discharge	1
A-53742-A	A53742A	HOUSING- End	1
54193	54193	EYE- Nut	1
54458-2A	544582A	HOUSING- Impeller	1
54551-2	545512	PLUG- Wing	1
54570-1	545701	HANDLE- Pivot	1
54571-1	545711	HANDLE- Pivot	1
54572-2	545722	HANDLE- Disconnect	1
54664	54664	GASKET	1
54665	54665	GASKET- Wear plate	1
54963-1	549631	STUD- 7/16-14 UNC	1
54956	54956	STRAINER	1
54957-1	549571	FITTING- Pump discharge	1
54958-1	549581	FITTING- Pump discharge	1
59910	59910	GASKET	1
62315	62315	DECAL	1
624501	624501	HOLDER- Spanner	1
62688	62688	SLINGER	1
80179	80179	SCREW- Mach. hex hd.	1
81060	81060	NUT- Hex (7/16-14)	1
83054	83054	LOCKWASHER	1
84020	84020	WASHER- Flat	1