



**BOSCH**

# Pn-Screwdriver - Ind.

180 WATT-SERIE | 0 607 453 434

---

## Table of Content

Spare parts list.....	2
Illustration - Type.....	5

## Spare parts list

Item	Part Number	Description
1	3 605 108 177	Motor Housing BLUE
2	3 604 090 050	Stator 180W
3	3 604 220 080	Rotor
5	3 605 700 107	Bearing Flange
6	1 900 905 044	groove ball bearing 7x19x6
7	3 605 700 148	Bearing Flange
8	1 900 905 028	groove ball bearing 7x17x5
9	3 600 700 200	Insert Pipe
12	3 600 100 030	Shim
25	3 600 100 007	Shim washer
26	3 606 300 046	Pinion Z=9
27	3 600 101 047	Stop Disc
28	3 606 334 085	Ring Gear Ø19,5 MM
29	3 606 337 041	Planetary-Gear Carrier
30	3 600 209 013	Spacer Ring BLACK
32	3 600 913 000	Needle-Roller Assembly INA K3x5x7
33	3 603 201 000	Needle Roller
34	3 600 700 050	Intermediate housing
35	1 903 201 042	Needle Roller DIN 5402-A3x11,8-G2
36	3 600 103 003	Stop Disc
38	3 606 337 192	Planetary-Gear Carrier
39	3 606 316 112	Cylindrical Gear
41	3 600 905 023	groove ball bearing
43	3 600 100 084	Supporting Disc
56	3 603 462 007	Fitting
57	3 600 206 005	Sealing disk
58	3 600 105 001	Shim washer
60	3 600 002 006	Strainer
61	3 603 462 000	Silencer
62	3 600 521 002	Screening Ring
65	1 900 210 112	O-Ring 15x2 MM
66	3 603 201 009	Straight Pin
67	2 917 690 036	Half-Length Grooved Pin ISO 8741-2x10-ST
68	3 608 750 021	Valve Cone
69	2 917 550 088	Straight Pin DIN 6325-3M6x32

**Spare parts list**

Item	Part Number	Description		
73	3 600 210 122	O-Ring	25,0x2,0 MM	BLACK
74	3 600 210 105	O-Ring	1,8x1,2 MM	
75	3 603 100 029	Straight Pin		
76	3 602 033 005	Push-Button		
77	3 604 610 016	Compression Spring		
78	3 600 210 104	O-Ring	16,0x1,0 MM	
79	3 600 313 011	Screw Plug		
80	2 912 411 407	Tapping Screw	DIN 7982-ST2,9x16-F-Z	
81	3 608 750 045	Housing		
82	3 602 000 002	Changeover Lever		
83	3 604 619 017	Compression Spring		
84	3 605 500 147	Housing Cover	BLUE	
87	3 601 010 010	Silencer		
91	2 600 100 648	Supporting Disc		
95	1 601 11A 3HF	Nameplate		
96	3 601 119 136	Manufacturer's nameplate		
99	3 601 110 572	Sticker		
100	3 605 125 054	Housing		
101	3 606 445 043	Clutch Element		
102	3 603 124 023	Output Shaft		
106	3 604 610 011	Compression Spring		
109	3 604 619 020	Compression Spring	BLUE	
110	3 600 224 053	Retaining ring		
113	3 600 499 023	Clamp Bushing		
114	3 600 921 001	Plain bearing		
115	3 601 023 011	Sealing plate		
116	3 600 134 014	Setting Ring		
119	3 600 190 038	Support Disc		
120	3 603 344 047	Catch Disk		
121	1 903 230 003	Ball	DIN 5401-2,5MM-III-ST	
125	3 600 202 020	Backup ring		
126	3 600 224 006	Retaining ring		
127	1 903 230 006	Ball	DIN 5401-3,5 MM-III-ST	
128	1 903 230 008	Ball	4,5 MM III DIN 5401-ST	
133	3 600 190 024	Washer		

**Spare parts list**

<b>Item</b>	<b>Part Number</b>	<b>Description</b>	
140	2 916 080 012	Locking Washer	DIN 6799-9-FSt
141	3 600 400 022	Protection Sleeve	
143	3 600 210 038	O-Ring	9,0x1,2 MM
145	3 600 210 116	O-Ring	
146	3 604 710 069	Straight Pin	
652	3 603 386 066	Hose fitting	
654	3 601 923 019	Suspension Loop	
657	3 607 950 027	Screwdriver	
706	3 604 618 003	Compression Spring	WHITE
753	3 607 000 074	Silencer	
801	3 607 031 510	Overriding Clutch	
802	3 607 031 505	Assembly Of Service Parts	
804	3 607 031 304	Assembly Of Service Parts	5 PIECE
868	3 608 750 042	Valve Cone	
876	3 607 030 332	Assembly Of Service Parts	

Illustration - Type - E

0 607 453 434; 435  
 Issue | 04-09-20  
 Stand |

Fig./Abb. 1

◆ Assemble pos. 101 and pos. 102;  
 now place in pos. 127 (10 ball bearings)!  
 Pos. 101 und Pos. 102 zusammenfügen;  
 danach 10 Kugeln Pos. 127 einfüllen!

