



Parts List for 0-2245 Type 0

Item Number	Part Number	Description	Qty Required
1	103152	DRIVER ARM-B8P-GRAY	1
2	102459	ARM-CLINCHER B8P	1
3	103153	OPER.LEVER-B8P-GRAY	1
4	102460	MAGAZINE-2115	1
5	102462	CORE-2115	1
6	102392	PUSHER-B8P	1
7	P627-S	BOSTITCH SPRING	1
8	100400	RETAINER- P6	1
9	100401	PIVOT PIN- P6	1
10	102461	DRIVER-FLEX	1
11	100404	CLINCHER ARM SPRING	1
12	100405	MAGAZINE SPRING	1
13	100406	DRIVE BEARING- P6	1
14	100407	MAGAZINE COVER- P6	1
15	100408	LEVER PIN- P6	1
16	85018	RING	1
17	100409	LOADING GUIDE- P6	1