



## Parts List for 345 Type 4

Item Number	Part Number	Description	Qty Required
1	872928	ARMATURE	1
2	872929	FIELD	1
3	N031654	BRUSH	2
4	395373-00	SWITCH	1
5	330072-97	CORD/10 FT/18-2	1
6	683784	TERMINAL	2
10	330003-64	BALL BEARING	1
11	878190	BEARING	1
12	696660	BEARING MOUNT	1
15	684188	BEARING	1
17	656284-00	NAMEPLATE	1
18	A12775	WARNING LABEL	1
20	872861	BAFFLE	1
21	872870	FAN	1
23	803483	BRUSH CAP	2
24	873497	BRUSH HOLDER	2
25	882408	CORD PROTECTOR	1
32	872927	JACKSHAFT ASSEMBLY	1
33	696949	BEARING	1
34	698778	JACKSHAFT COVER	1
35	688672	SPACER	1
36	862006	O RING	1
37	697505	WASHER	1
38	872875	RETAINING RING	1
50	897446	BASE	1
51	883748	HANDLE COVER	1
52	655748-00	MOTOR HOUSING	1

## Parts List for 345 Type 4

Item Number	Part Number	Description	Qty Required
53	883569	GEAR HSG/UPPER GRD	1
63	696641	TELE-GUARD	1
81	893683	WASHER	2
82	696657	BLADE-BOLT	1
84	696669	LEVER	2
85	885516	NUT	2
89	894303	SPRING	1
100	881538	SET SCREW	2
101	884677	SCREW	3
102	879678	SCREW	5
103	881090	SCREW	1
104	684179	RETAINING RING	1
105	694010	SCREW	4
108	889702	KNOB	1
109	879525	SCREW	1
110	697382	RIVET	1
111	697381	COVER	1
112	893314	SPRING	1
113	878877	RETAINER CLIP	1
114	698367	BUMPER	1
115	879548	SCREW	1
117	878381	SEAL	1
119	696677	SPRING	1
120	878407	LOCK PIN	1
121	859359	WASHER	1
122	696656	RETAINING-RING	2
123	696658	GUIDE-PLATE	1

## Parts List for 345 Type 4

Item Number	Part Number	Description	Qty Required
124	696796	SCREW	2
125	882187	SCREW	1
126	696667	RETAINING-RING	1
127	894223	SCREW	2
128	696668	WASHER	1
129	654936-00	LEVER	1
130	858792	WASHER	1
131	865015	SNAP RING	1
134	698241	WAVE WASHER	2
135	893521	BOLT	1
136	872906	FIELD SCREW	2
138	883486	SCREW	3
139	801530	WASHER	1
140	889465	WASHER	1
141	895510	RIP GUIDE	1
142	882456	WRENCH	1
800	879751	LUBRICANT 4 LBS	1
800	878499	TUBE GREASE	1
856	698460	BASE INSERT ASSY	1
856	696167	DUST BAG ASSY-	1
856	877694	EXHAUST NOZZLE	1
856	839330	SPRING ELBOW RE	1
856	698034	HOSE	1
856	39332	VACUUM/HOSE ASSEMBLY	1