



# Operating Instructions and Parts Manual

## Web Strap Ratchet Hoists


### JWS-Series



**JET**  
427 New Sanford Road  
LaVergne, Tennessee 37086  
Ph.: 800-274-6848  
[www.jettools.com](http://www.jettools.com)

**Part No. M-352100**  
Edition 1 07/2016  
Copyright © 2016 JET

11.1.1 JWS-2A Web Strap Hoist – Exploded View



## 11.1.2 JWS-2A Web Strap Hoist – Parts List

Index No.	Part No.	Description	Size	Qty
1	TS-1504031	Hex Socket Head Cap Screw	M8x16	1
2	TS-2361081	Lock Washer	M8	1
3	TS-1550061	Flat Washer	M8	1
4	JWS2A-04	Wing Nut		1
5	JWS2A-05	Handle Assembly		1
6	JWS2A-06	O-Ring		1
7	JWS2A-07	Brake Gear		1
9	JWS2A-09	Plate A Weldment (large hole)		1
10	JWS2A-10	Plastic Disc (large hole)		1
11	JWS2A-11	Drum		1
12	JWS2A-12	Plate B (small hole)		1
13	JWS2A-13	Pawl		1
14	JWS2A-14	Pawl Screw	M8	1
15	JWS2A-15	Top & Bottom Tube		2
16	JWS2A-16	Clevis Pin with Cotter	M12x29.5	2
17	SH081400	Hex Cap Screw	M8x70	1
18	JWS2A-18	Web Strap Restraint		1
19	SH069200	Hex Cap Screw	M6x8	2
20	TS-1541031	Hex Nylon Lock Nut	M8	3
21	JWS2A-21	Plastic Disc (small hole)		1
22	JWS2A-22	Swivel Shackle Assembly		1
23	JWS2A-23	Pawl Spring		1
24	JWS2A-24	Eye Hook and Latch Assembly		2
25	JWS2A-25	Web Strap		1
26	JWS2A-26	Collar		2
27	JWS2A-27	Hex Cap Screw		1
28	JWS2A-28	Clamping Block		1
29	TS-1504011	Hex Socket Head Cap Screw	M8x10	2
30	JWS2A-30	Pin		1
31	F006052	C-Ring, External	30mm	1
32	JWS2A-32	Middle Tube		1
33	JWS2A-33	Web Strap Roller		1
34	JWS2A-34	Plastic Cushion		1
35	JWS2A-35	Web Strap Guide Washer		2
	LM000215	Label - Not For Lifting (not shown)	5/8 x 2-5/8 in	1