

IMPORTANT — To assure product **SAFETY** and **RELIABILITY**, repairs, maintenance or adjustments should be performed by **MAKITA** Service Centers or other qualified service organizations. Always use **MAKITA** replacement parts.




Fig.	Part No.	Qty. Used	Description	Fig.	Part No.	Qty. Used	Description
1	911216-1	2	SCREW M5x14	27	664074-1	1	CORD WITH PLUG (2x18x16;SJ)
2	284042-4	1	REAR COVER	28	911233-1	1	SCREW M5x20
3	285016-8	1	BEARING COVER	29	911153-9	2	SCREW M4x28
4	411372-2	1	SCALE RING	30	911131-9	2	SCREW M4x18
5	263002-9	1	RUBBER PIN 4	31	687002-9	1	STRAIN RELIEF
6	156399-2	1	MOTOR HOUSING (w/ 2 ea. Brush Holder 643653-8 & Screw M5x8 913206-0)	32	911103-4	1	SCREW M4x6
7	181047-4	2	CARBON BRUSH (CB-154)	33	342290-2	1	LOCK PLATE
8	643650-4	2	BRUSH HOLDER CAP	34	953101-2	2	RIVET
9	341381-6	1	STAY	35	312034-4	1	ROUTER BASE
10	623032-6	1	FIELD ASSEMBLY (w/ Fig. 25)	36	271213-2	1	KNOB
11	211068-3	1	BALL BEARING 6200LB	37	911207-2	4	SCREW M5x10
12	681623-9	1	INSULATION WASHER	38	924326-5	1	SCREW M6x20
13	911280-2	2	BOLT M5x55	39	231005-1	1	COMPRESSION SPRING 7
14	613302-1	1	ARMATURE ASSEMBLY (Incl. Fig. 11, 12, 14, & 15)	40	411023-7	1	BASE PLATE
15	241621-1	1	FAN	41	411374-8	1	HANDLE (L)
16	253748-5	2	WASHER 12	42	652014-1	4	SCREW M4x8
17	312036-0	1	MOTOR BRACKET	43	931102-0	2	HEX NUT
18	911241-2	4	SCREW M5x25	44	924326-5	1	SCREW M6x20
19	211129-9	1	BALL BEARING 6201DDW	45	231005-1	1	COMPRESSION SPRING 7
20	285612-2	1	BEARING RETAINER	ACCESSORIES			
21	911216-1	2	SCREW M5x14	401	763803-0	1	1/4" COLLET SLEEVE
22	763602-0	1	1/2" COLLET CHUCK (w/ 1/2" Cone 763623-2)	403	781208-2	1	WRENCH 21
23	411375-6	1	HANDLE (R)	404	781209-0	1	WRENCH 23
24	651008-3	1	SWITCH	405	123029-0	1	STRAIGHT GUIDE ASS'Y (Incl. Fig. 44, 45)
25	654020-2	2	GARTER SPRING				
26	682503-2	1	CORD GUARD				