



## Parts List for 382 Type 2

Item Number	Part Number	Description	Qty Required
1	616618-00SV	ARMATURE & BRGS	1
2	615795-00SV	FIELD	1
3	445861-25	BRUSH	2
4	445860-00	SPRING,BRUSH	2
5	449899-05	RING,BRUSH	1
6	656494-00	SWITCH	1
7	330072-97	CORD/10 FT/18-2	1
8	330003-17	BEARING,BALL	1
9	605040-05	BEARING, BALL	1
10	616020-00	FAN	1
11	N062269	CLAMSHELL SET	1
13	330005-01	PROTECTOR,CORD	1
14	380414-00	CLAMP,CORD	1
15	N517315	CAP	1
16	144989-00	LEAD ASSY.	1
17	445964-00	TERMINAL	2
18	825209-00	TERMINAL	2
19	610078-00	SHROUD CLAMSHEL	1
21	286181-00	RETAINER&SCREWS	1
22	603637-00	BRG. RETAINER	1
23	N110363	BEARING	1
24	151281-08	PAD	1
25	151549-00	BAFFLE	1
26	151553-00	SEAL,DUST	1
30	56194-00	RING,O	1
32	700871-00	O RING	1
34	098012-11	MACH SCREW	1

## Parts List for 382 Type 2

Item Number	Part Number	Description	Qty Required
35	146929-01	SCREW	3
36	330019-02	SCREW,PLASTITE	2
37	330019-08	SCREW	2
38	330019-03	SCREW,PLASTITE	2
39	330019-13	SCREW,PLASTITE	7
40	151652-00	WASHER,CONE	1
41	N063028	IDENT. LABEL	1
42	N538050	RATING PLATE	1
43	151669-00	RING,RETAINING	1
44	144956-00	NUT	2
50	N063102SV	DUST BAG	1
51	N066087	WARNING LABEL	1
52	A27275	WARNING LABEL	1