



Item No.	Part No.	Qty. Used	Description	Item No.	Part No.	Qty. Used	Description
1	125102-2	1	SPEED CHANGE LEVER ASS'Y				
2	183794-3	1	HOUSING SET (Incl. 14,15)				
4	266130-9	9	TAPPING SCREW BIND PT 3X16				
5	232182-2	1	LEAF SPRING				
6	417283-9	1	F/R CHANGE LEVER				
7	650556-9	1	SWITCH C3NA-1-M1 SINGLE VAR/REV				
8	643909-9	1	BATTERY HOLDER				
9	251468-5	1	- FLAT HEAD SCREW M6X22				
11	125237-9	1	GEAR ASS'Y				
12	629817-8	1	DC MOTOR				
13	911003-8	2	PAN HEAD SCREW M3X6				
14	819001-5	1	MAKITA LABEL				
15	183794-3	1	HOUSING SET (Incl. 2,14)				
				<u>ACCESSORIES</u>			
				10	763185-0	1	KEYLESS DRILL CHUCK 10
				A01	414938-7	2	BATTERY COVER
				A02	DC1804	1	BATTERY CHARGER
				A03	784636-0	1	+/- BIT 2-65
				A04	824635-1	1	PLASTIC TOOL CASE (Incl. 1 Ea. Slide Latch Set 186347-7, Makita Label 819143-5)
				A05	193983-2	1	BATTERY PA12