


ROUTER

6302
6702
6902
513T6/T7



WARNING: Electrical repairs should only be attempted by trained repairmen. Contact the nearest Porter-Cable Service Center or other competent repair center.

Parts List for 630 Type ALL TYPES

Item Number	Part Number	Description	Qty Required
1	683459	ARMATURE 115V	1
1	682058	ARMATURE 115V	1
1	874588	ARMATURE-220	1
1	903660	ARMATURE	1
1	000000-00	No Longer Available	1
1	694209	ARMATURE	1
1	680913	FAN	1
1	696328	FAN	1
1	000000-00	No Longer Available	1
1	874299	FAN	1
2	683461	FIELD 115V	1
2	874589	FIELD-220	1
2	000000-00	No Longer Available	1
2	699326	FIELD	1
2	694210	FIELD	1
2	682114	FIELD 115V	1
2	803104	LEAD	1
3	869659	BRUSH	2
3	869659	BRUSH	2
3	803483	BRUSH CAP	2
3	873497	BRUSH HOLDER	2
4	876320	SWITCH.	1
4	842606	SWITCH	1
5	A11126	CORDSET	1
5	879182	CORD	1
5	879758	CORD-EURO	1
11	855284	BEARING	3

Parts List for 630 Type ALL TYPES

Item Number	Part Number	Description	Qty Required
11	858464	BEARING	3
11	878064	BEARING	3
52	903967	CASING & PINS FRONT	1
52	903967	CASING & PINS FRONT	1
52	904663	CASE-FRONT	1
52	899192	REAR HOUSING	1
52	888727	MOTOR HOUSING CAP	1
60	849314	TERM	1
81	875893	COLLET NUT	1
83	872793	CHUCK	1
83	42999	1/4 INCH COLLET ASSY	1
83	42999	1/4 INCH COLLET ASSY	1
83	42975	3/8 INCH COLLET ASSY	1
83	42975	3/8 INCH COLLET ASSY	1
83	42950	1/2 INCH COLLET ASSY	1
83	876669	COLLET 1/4 INCH	1
83	876671	COLLET 1/2 INCH	1
83	876670	COLLET 3/8 INCH	1
83	42999	1/4 INCH COLLET ASSY	1
83	42999	1/4 INCH COLLET ASSY	1
98	823030	SNAP-RING	10
100	878813	SCREW	10
103	803632	SET-SCREW	10
103	804360	SCREW	10
104	803496	WASHER	10
105	842597	PLUG	1
106	881082	SCREW MACHINE STEEL	10

Parts List for J-630 Type ALL TYPES

Item Number	Part Number	Description	Qty Required
106	681260	SCREW & WASHER	10
106	838312	SCREW	10
106	863393	SCREW	10
107	802430	LOCKWASHER	10
108	802426	RING	10
110	901266	STRAIN RELIEVER	1
111	800835	PIN	10
112	842610	SPRING-PRELOAD	10
113	682063	CONNECTOR VS	1
114	842598	BRACKET SWITCH	1
114	876396	BRACKET	1
115	802764	SCREW	10
117	801374	SCREW	10
120	681260	SCREW & WASHER	10
121	874137	CORD CLAMP	1
122	877817	SCREW	10
223	872998	DEPTH RING	1
225	800995	BASE KNOB	1
225	803674	KNOB	1
226	801821	WASHER	10
227	874582	CLAMP KNOB	1
228	823374	WASHER	10
229	802306	HEX HEAD SCREW	1
230	42186	ROUTER SUB-BASE	1
231	688860	SCREW	10
231	874117	SCREW	10
232	685526	SCREW	10

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for J-630 Type ALL TYPES

Item Number	Part Number	Description	Qty Required
233	903010	BASE HOUSING	1
233	886264	BASE HOUSING	1
234	800869	SPRING	3
235	42160	ROUTER EDGE GUIDE	1
236	803160	SCREW	10
237	882810	KNOB	1
238	824588	ROD GUIDE	1
238	824588	ROD GUIDE	1
239	849314	TERM	1
240	695474	CUTTER SHAFT ASSY	1
241	696696	SCREW	10
856	683157	WRENCH OPEN END	1
856	683157	WRENCH OPEN END	1
856	883356	BIT	1
856	A22709	OPEN-END WRENCH	1
856	A22709	OPEN-END WRENCH	1
861	903049	CARRYING CASE	1
861	902829	CARRYING CASE	1
861	000000-00	No Longer Available	1
861	000000-00	No Longer Available	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenetwork.com for current parts information.