



SERVICE PARTS LIST


BULLETIN NO.
55-40-1953

| | | | |
|--|----------|--------------------|----------|
| SPECIFY CATALOG NO. AND SERIAL NO. WHEN ORDERING PARTS | | REVISED BULLETIN | DATE |
| WORM DRIVE SAW | | 55-40-1952 | July '92 |
| CATALOG NO. | 6378-4 | WIRING INSTRUCTION | |
| STARTING SERIAL NO. | 621-3046 | 58-03-0601 | |

EXAMPLE:

| | |
|----|---|
| 00 | 0 |
|----|---|

 Component Parts (Small #) Are Included
 When Ordering The Assembly (Large #).



| FIG. PART NO. | DESCRIPTION OF PART | NO. REQ. |
|---------------|-------------------------------------|----------|
| 1 | 220 Volt Armature | (1) |
| ★ 2 | 8-16 x 2-1/2" Pan Hd. Plastite T-20 | (2) |
| 3 | 220 Volt Field | (1) |
| 4 | Ball Bearing | (1) |
| 5 | Brush Tube | (1) |
| 8 | Motor Housing Assembly | (1) |
| 9 | 8-32 Hex Nut | (5) |
| 10 | Switch Service Kit | (1) |
| 11 | 8-16 x 3/8" Pan Hd. Plastite T-20 | (1) |
| 12 | Switch Lockwasher | (4) |
| 13 | Left Handle Half | (1) |
| 14 | 8-32 x 1-1/16" Pan Hd. T-20 | (5) |
| 15 | Brush Retaining Screw | (2) |
| 16 | Carbon Brush Assembly | (2) |
| 17 | Brush Holder Assembly | (2) |
| 18 | 8-32x5/8" Pan Hd. T-20 | (2) |
| 29 | Internal Retaining Ring | (1) |
| ★ 30 | Ball Bearing | (1) |
| 31 | Worm Spacer | (1) |
| 32 | Armature Seal | (1) |
| 33 | No. 10 Lockwasher | (1) |
| 34 | 10-24 Hex Nut | (1) |
| 35 | Gear Case | (1) |
| 36 | Top Handle | (1) |

| FIG. PART NO. | DESCRIPTION OF PART | NO. REQ. |
|---------------|---|----------|
| 37 | 06-82-5320 8-32 x 5/8" Pan Hd. T-20 | (2) |
| ★ 38 | 06-82-7224 10-14x 1" Pan Hd. Plastite T-25 | (3) |
| 39 | 06-95-5690 3/8-16 x 3/4" Washer Hd. Hex Screw | (1) |
| 40 | 45-88-7475 Washer | (2) |
| 41 | 32-91-0115 Worm | (1) |
| 42 | 45-36-1020 Spacer | (1) |
| 43 | 02-04-1050 Ball Bearing | (1) |
| 44 | 45-88-0601 Washer | (1) |
| 45 | 06-57-5050 5/16-24 Lock Nut | (1) |
| 46 | 43-44-0240 Gasket | (1) |
| 47 | 31-15-0115 Hood | (1) |
| 48 | 06-82-5320 8-32x5/8" Pan Hd. T-20 | (4) |
| 50 | 42-76-0470 Locking Collar | (1) |
| 52 | 06-82-5316 8-32x1/2" Pan Hd. T-20 | (4) |
| 58 | 02-50-2423 Needle Bearing | (1) |
| 59 | 32-90-0107 Worm Gear | (1) |
| 61 | 38-50-5191 Spindle | (1) |
| 62 | 45-06-0260 Spindle Seal | (1) |
| 63 | 34-80-2960 Internal Retaining Ring | (1) |
| 64 | 02-04-1748 Ball Bearing | (1) |
| 65 | 28-53-0270 Guard Hub | (1) |
| 66 | 34-40-2120 O-Ring | (1) |
| 68 | 34-60-2150 Retaining Ring | (1) |
| 71 | 43-34-0700 Inner Flange | (1) |
| 73 | 43-34-0300 Outer Flange | (2) |
| 74 | 06-75-0478 3/8-24 L.H. Blade Screw (Long) | (1) |
| | 06-75-0473 3/8-24 L.H. Blade Screw (Short) | (1) |
| 75 | 06-92-2520 Stud | (1) |

| | | |
|------|----------------------------------|-----|
| ★ 76 | 22-64-4525 Cord Set | (1) |
| 78 | 44-76-0170 Cord Protector | (1) |
| 79 | 22-84-0700 Fan | (1) |
| 81 | 34-40-1610 O-Ring | (1) |
| 82 | 34-40-4170 O-Ring | (2) |
| 83 | 45-88-0610 Washer | (1) |
| 84 | 40-50-8325 Spring | (1) |
| 85 | 45-08-0300 Lockshaft | (1) |
| 86 | 34-60-0525 Retaining Ring | (1) |
| 87 | 44-40-0650 Spindle Lock Nut | (1) |
| 88 | 45-88-7476 Washer | (2) |
| | 05-89-0045 Switch Terminal Screw | (4) |
| | 22-33-0305 Suppressor | (1) |
| | 43-62-0880 Side Handle | (1) |

FIG. LUBRICATION
 35 1/2 Oz. Worm Drive Oil, No. 49-32-0050.

NOTE:
 Parts In Bag - (Figs. 36, 37, 68, 71, 73, 74 & 43-62-0880).

MILWAUKEE ELECTRIC TOOL CORPORATION
 13135 W. LISBON RD., BROOKFIELD, WI 53005