



Parts List for 6931 Type 8

Item Number	Part Number	Description	Qty Required
300	A22764	BASE	1
303	897187	COLUMN	2
304	698805	TURRET	1
305	896769	STOP SCREW	1
306	892552	LEVER	1
307	872242	SCREW	1
308	699675	CLAMP SCREW	1
309	892531	SPRING SS/A	1
310	699563	SET SCREW	1
311	699552	CLAMP PLUG	1
312	872729	ROLLED PIN	1
313	875050	KNOB	2
314	802425	WASHER	1
316	802752	WASHER	1
317	873309	SCREW	1
318	699399	POINTER	1
319	881290	KNOB	1
321	699991	DEPTH ROD	1
322	892174	NUT	1
323	699553	STOP COLLAR	1
324	850802	WASHER	1
325	A13321	SCALE	1
326	897161	KNOB	1
327	873315	CLAMP	1
328	699558	BUSHING	1
329	699400	SPRING GUIDE	1
330	801752	SCREW	1

Parts List for 6931 Type 8

Item Number	Part Number	Description	Qty Required
331	862641	NUT	1
332	883806	SCREW	1
333	685533	WASHER	1
334	850552	SPRING	1
335	895591	WASHER	1
336	860687	BALL	1
338	A22761	ID LABEL	1
339	886538	SCREW	1
340	872762	SHIELD	1
341	875807	SUB BASE	1
341	42186	ROUTER SUB-BASE	1
342	874117	SCREW	3
342	688860	SCREW	3
344	699556	BUSHING-STOP	1
345	699561	SPRING	1
346	872789	SHLDER BEARING	1
347	802430	LOCKWASHER	1
348	885517	NUT	1
350	903595	NUT	1
356	A24271	NAMEPLATE	1
361	A22762	WARNING LABEL	1
856	802876	ALLEN WRENCH	1
856	842323	WRENCH HOLDER	1