



Parts List for 698 Type 1

Item Number	Part Number	Description	Qty Required
1	886364	BOX-SWITCH	1
2	000000-00	No Longer Available	10
5	852310	SCREW	10
6	886370	WASHER	10
7	886515	SCREW	10
8	489105-00	SWITCH	1
8	5140066-09	SWITCH KIT	1
8	875330	SWITCH KEY	1
10	884725	LEG(RIGHT OR LEFT)	1
11	884731	TABLE TOP	1
12	884778	FENCE	1
13	884779	FENCE BRACKET	1
14	884820	BRACKET (GUARD)	1
15	884821	TOP GUARD	1
16	884822	FRONT GUARD	1
17	884823	REAR CUTTER GUARD	1
18	884887	PIN	1
19	884888	PIN	1
20	697965	RET RING	1
21	886366	HAIR PIN	1
22	884891	SPRING	1
23	884892	SCREW	10
28	885309	CORDSET (MALE)	1
29	885310	CORDSET (FEMALE)	1
30	694949	STARTING PIN	1
31	886513	SCREW	10
32	892956	SCREW	10

Parts List for 698 Type 1

Item Number	Part Number	Description	Qty Required
32	885048	RTR MTG SCREW5/16X18	1
32	881305	RTR MTG SCREW 10X24	1
33	901965	NUT	10
34	800192	NUT	10
35	822133	LOCK WASHER	10
38	884730	INSERT (2 5/16 ID)	1
38	884729	INSERT (1 1/4 ID)	1
40	884893	SCREW	10
41	884894	BOLT	1
42	884895	KNOB	1
46	886331	CAUTION PLATE	1
47	886332	WARNING PLATE	1
48	886398	STRAIN RELIEF	1
49	000000-00	No Longer Available	1
49	886365	MITER GAUGE	1
49	1087524	KNOB	1
846	884898	HARDWARE PKG	1