


HUSQVARNA ROTARY LAWN MOWER - - MODEL NUMBER 7021P (MFG. ID. NO. 96133001902)



HUSQVARNA ROTARY LAWN MOWER - - MODEL NUMBER 7021P (MFG. ID. NO. 96133001902)

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	580 84 91-02	Control Bar, Molded	44	532 18 41-93	Bolt, Rear Door
2	580 63 87-03	Upper Handle	45	532 15 04-06	Hex Head Thread Rolling Screw 3/8-16 x 1
3	580 63 86-03	Bar, Lower Handle	46	532 40 47-63	Danger Decal
4	581 90 21-01	Rope Guide	47	532 42 65-89	Nut, Hex
5	581 91 26-01	T-Knob	48	532 41 06-01	Axle Arm Assy., Rear, RH
6	532 19 15-74	Handle Bolt	49	580 33 46-01	Wheel & Tire Assembly, Rear 12 x 1-3/4
7	532 06 64-26	Wire Tie	50	581 00 21-12	Grassbag
8	874 78 05-12	Bolt, Hex Head 5/16-18 x 3/4	51	532 14 72-86	Hinge Rod
9	532 15 41-32	Hinge Bracket	52	532 44 19-50	Kit, Housing (Includes Key Number 46)
10	581 82 58-01	Mulcher Door	53	532 85 10-84	Screw, Hex Head, Grade 8 3/8-24 x 1-3/8
11	532 41 53-50	Engine Zone Control Cable			
12	532 17 88-48	Screw, Hex Washer Head #10-16 x 5/8	54	532 85 02-63	Helical Lockwasher
13	532 43 00-34	Up-Stop Bracket	55	532 85 10-74	Hardened Washer
14	532 18 23-98	Handle Knob	56	580 25 81-01	21" Blade
15	532 05 17-93	Hairpin Cotter	57	532 41 83-73	Blade Adapter
18	817 60 04-06	Screw	58	532 15 21-24	Hinge Spring
19	532 40 66-89	Axle Arm Assembly, Front, LH	59	- - -	Engine, Honda, Model Number GCV160-LAOS3B (For engine service and replacement parts, call Honda Engines at 1-800-426-7701)
20	532 40 66-90	Axle Arm Assembly, Front, RH			
21	532 41 86-55	Kit, Rear Skirt			
22	532 40 64-28	Selector Spring, Front	61	532 40 91-48	Flanged Locknut
23	581 42 56-01	Rear Door Assembly	62	873 80 04-00	Nut, Hex
25	580 91 56-03	Handle Bracket, LH	65	532 08 83-48	Washer, Flat
26	580 91 57-03	Handle Bracket, RH	66	532 19 74-80	O-Ring
29	532 41 05-94	Wheel Adjusting Bracket, Front	73	532 40 16-30	Washer, Curved, Cylindrical
30	532 40 16-29	Spacer	74	532 12 50-78	Washer, Special, Engine
31	532 18 55-95	Discharge Deflector	75	532 41 36-93	Kit, Rear Baffle (Includes 3 Screws)
32	532 44 15-59	Selector Spring, Rear			
33	532 70 10-37	Selector Knob	76	532 41 05-89	Baffle, Rear
34	532 41 06-00	Axle Arm Assy., Rear, LH	77	817 41 13-12	Screw, Rear Baffle
35	532 75 11-53	Locknut, Hex 5/16-18	83	532 42 85-01	Baffle, Front
36	532 40 16-38	Shoulder Bolt 5/16-18	84	817 00 05-10	Screw, Hex Head 5/8-16
37	532 41 08-31	Wheel & Tire Assembly, Front 8 x 1-3/4	87	532 43 75-16	Plug, Handle Bar
39	532 40 91-49	Nut, Hex	88	872 25 05-05	Bolt, Carriage
40	532 41 19-49	Frame, Grassbag	89	873 97 05-00	Nut, Hex
41	532 19 41-86	Screw, Hinge	--	532 40 47-64	Warning Decal (not shown)
42	532 40 54-21	Spring, LH	--	115 63 29-32	Operator's Manual, English / French
43	532 40 54-23	Spring, RH	--	115 63 29-46	Operator's Manual, Spanish

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm

IMPORTANT: Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.