

: **ASM 9-6-150 (9,6V)**  
 : **71120500980**



				(USD)	
0010	54199012020	Motor	1		-
0015	30762273990	Electronics	1		-
0017	54199017800	Motor	1		-
0020	30109173026	Planetary gear	1		-
0030	30762426980	Foil conductor Set	1		-
0032	32805204002	Switch pushbutton	1		-
0033	30240264009	Holder	1		-
0040	32436070001	Flange	1		-
0050	30103051001	Clutch ring	1		-
0070	30508040010	Bush	1		-
0080	41708017002	Ball	10		-
0090	41708018000	Ball	9		-
0100	30103052000	Clutch ring	1		-
0110	30104135008	Tool holder	1		-
0120	30901371000	Spiral spring	1		-
0130	32009074002	Ring	1		-
0140	41708014001	Ball	3		-
0150	32009073004	Adjusting ring	1		-
0165	32408310990	Disc	1		-
0200	41701010054	Grooved ball bearing	1		-
0210	42615110009	Circlip	1		-
0215	42616006007	Circlip	1		-
0220	30503154000	Sleeve	1		-
0230	30901315002	Spiral spring	1		-
0240	32601242005	Ring	1		-
0250	42615081002	Circlip	1		-
0265	31912070030	Motor housing	1		-
0280	30501351000	Sleeve	1		-
0290	32805203004	Switch pushbutton	1		-
0300	32414115000	Housing insert	1		-
0310	32424025004	Cover	1		-
0320	32804002010	Slide switch	1		-
0330	30901357005	Spiral spring	1		-
0340	43072015000	Screw	9		-
0350	40612142004	Sealing ring	1		-
0370	31415061003	Pressure piece	2		-
0380	43035117034	Cylinder head screw	2		-
0410	30901370000	Spiral spring	1		-
0420	42402016990	Disc	1		-
5000	32123002006	Adjustment spanner - torque	1		-
9000	34101094060	Operating instructions	1		-
9010	34151060000	List of spare parts ASM	1		-

:  
:

**ASM 9-6-150 (9,6V)**  
**71120500980**

- 7 112 07 - ASM 9-2
- 7 112 06 - ASM 9-4
- 7 112 05 - ASM 9-6/150
- 7 112 04 - ASM 9-6
- 7 112 03 - ASM 9-9
- 7 112 02 - ASM 12-9
- 7 112 01 - ASM 12-12
- 7 112 11 - ASM 9-6-2St
- 7 112 10 - ASM 9-4-2St

