



## Parts List for 738 Type 1

Item Number	Part Number	Description	Qty Required
1	900709	ARMATURE	1
1	898877	ARMATURE	1
1	A05447	ARMATURE	1
1	878904SV	FAN	1
2	900854	FIELD	1
2	A05448	FIELD	1
2	898876	FIELD	1
3	874289	BRUSH & RETAINER ASY	2
3	865323	BRUSH HOLDER	2
3	865321	BRUSH INSULATOR	2
4	A02928	SWITCH	1
4	5140066-97	SWITCH	1
4	883498	SWITCH & TRIAC	1
4	893735	SWITCH	1
5	891461	CORD & PLUG	1
5	A10193	CORDSET	1
11	855284	BEARING	1
11	330003-17	BEARING,BALL	1
15	883095	BEARING	1
31	879401	GEAR	1
40	N074353	RECIP-SHAFT KIT	1
40	890817	RECIP SHAFT	1
52	912305	HOUSING	1
57	893069	HANDLE SET	1
57	892791	HANDLE SET	1
57	892792	HANDLE SET	1
81	879465	BLADE CLAMP	1

## Parts List for 738 Type 1

Item Number	Part Number	Description	Qty Required
81	880951	BLADE SCREW	1
82	897774	COLLAR	1
100	695077	MOUNTING BRKET TRIAC	1
101	690673	WIRE TIE	1
107	882703	SCREW	10
108	880972	INSULATOR BOOT	1
114	694432	BEARING MOUNT	1
121	882704	SCREW	10
125	879421	SCREW	10
130	879414	INTERMEDIATE PLATE	1
138	879458	PLATE	1
141	883097SV	DRIVE SHAFT	1
142	684931	WASHER	10
143	890819	WOBBLE PLATE	1
147	802302	RING	1
148	879429	SPACER	1
150	883213	CARRIER TUBE ASSY	1
153	882348	FELT SEAL	1
158	879423	FRONT HOUSING	1
159	879457	FELT SEAL	1
161	891672SV	SHOE & BRACKET ASSY.	1
163	849235	SCREW	10
165	879463	SCREW	10
172	882185	SCREW MACHINE STEEL	10
179	900826	SCREW	10
187	892440	SET SCREW	10
188	880952	PLUG	1

## Parts List for 738 Type 1

Item Number	Part Number	Description	Qty Required
190	853246	RING	1
196	882255	SCREW	10
197	648924-00	SPRING	1
198	884696	RETAINER KIT	1
199	648594-00	CLAMP PIN	1
200	801852	SEAL	1
203	902998	SEAL	1
214	883502	COIL 220V	1
215	A02928	SWITCH	1
216	901266	STRAIN RELIEVER	1
217	879447	PLUG	1
218	879449	O RING	1
219	694010	SCREW	10
221	802905	ALLEN WRENCH	1
222	842323	WRENCH HOLDER	1
800	5140061-28	GREASE	1
800	5140061-28	GREASE	1
861	000000-00	No Longer Available	1
861	887712	LATCH CARRYING CASE	1