



Parts List for 78-461 Type 1

Item Number	Part Number	Description	Qty Required
1	1350304S	SCREW	1
1	000000-00	No Longer Available	1
2	1350276S	WASHER	1
3	1350321S	ANTI-KICKBACK FINGER	1
3	1350997S	WARNING LABEL	1
4	1350320S	SPRING	1
5	1351465	BLADE ASSY	1
6	1350321S	ANTI-KICKBACK FINGER	1
7	1350276S	WASHER	1
8	1350304S	SCREW	1
9	1350085S	KNOB	1
10	1351463	SPLITTER MOUNT ASSY	1
11	1350084S	SPRING	1
12	1351058S	SCREW	1
13	1351460	COVER PLATE ASSY	1
14	1350311S	SCREW	3
15	1350307S	SCREW	1
16	1351061	LOCKWASHER	1
17	1350308S	FLAT WASHER	1
18	1350305S	SCREW	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.