


HUSQVARNA ROTARY LAWN MOWER - - MODEL NUMBER 917.375820



REPAIR PARTS


HUSQVARNA ROTARY LAWN MOWER - - MODEL NUMBER 917.375820

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	196403	Upper Handle Assembly (Includes Foam Grip)	30	180413X004	Axle Arm Assembly	56	88652	Screw, Hinge 1/4-20 x 1-1/4
2	183567	Engine Zone Control Cable	31	189808X418	Selector Knob	57	51793	Hairpin Cotter
3	850733X004	Bracket, Upstop	32	198169X004	Selector Spring	58	151590X498	Lower Handle
4	166649	Mulcher Plug	33	189917X418	Mulcher Door	59	191574	Handle Bolt
5	66426	Wire Tie	34	146630	Spacer	60	74760612	Bolt, Hex Head 3/8-16 x 3/4
6	189713X418	Handle Knob	35	700325X007	Wheel Adjusting Bracket	62	199314	Debris Shield
7	750634	Screw	36	175735	Hinge Bracket Assembly	63	192325	Screw, Debris Shield
8	194580X422	Control Bar	37	150078	Screw, Sems, Thread Cutting 5/16-18 x 3/4	64	- - -	Engine, Briggs & Stratton, Model No. 125K02-0654-E1 (For engine service and replacement parts, call Briggs & Stratton at 1-800-233-3723)
9	193679	Rear Door Assembly (Includes Springs)	38	402574X418	Discharge Deflector	65	197480	O-Ring
10	128415	Pop Rivet	39	195915X479	Handle Bracket Assembly, LH	69	197991	Clip, Cable
11	150050	Screw, Self-Tapping #10-24 x 5/8	40	195914X479	Handle Bracket Assembly, RH	70	182748	Foam Grip
37	12	54583	12	54583	Screw, Hex Head, Sems 1/4-20 x 1/2	71	188839X004	Mounting Bracket, DebrisShield
14	195622X479	Back Plate	41	150406	Bolt, Hex Head, Engine 3/8-16	72	182227	Screw #8
15	700365X479	Side Baffle	42	193000	Spring, Torsion	73	197162	Belt Keeper
16	176655X479	Discharge Baffle	43	73800400	Nut, Hex, Nylock	74	182228	Nut, Hex
17	140661X479	Rear Baffle	44	197556	Kit, Lawn Mower Housing (Includes Key #14, 15 and 51)	- -	161058	Warning Decal (not shown)
18	132004	Keps Locknut 1/4-20	45	175650	Rod, Hinge	- -	402735	Owner's Manual
19	194788	Rope Guide	46	194037	Blade Adapter / Pulley	Available accessories not included with mower:		
20	189008	Rear Skirt	47	141114	Blade, 22"	- -	71 33623	Gas Can (2.5 Gallon Container)
21	170938	Spring, Rear Door, LH	48	851074	Washer, Hardened	- -	71 33500	Fuel Stabilizer
24	170939	Spring, Rear Door, RH	49	850263	Washer, Helical	- -	71 33000	SAE 30W Oil (20 Ounce Bottle)
25	145212	Nut, Hex, Flanged	50	851084	Screw, Machine, Hex Head 3/8-24 x 1-3/8 Grade 8			
26	184193	Bolt, Rear Door	51	170031	Front Baffle			
27	193906X460	Wheel & Tire Assembly, Rear	52	85463	Danger Decal			
28	142748	Bolt, Shoulder 3/8-16 x 1	53	17600406	Screw			
29	61651	Washer, Belleville	54	88348	Washer, Flat			
			55	751592	Locknut, Hex 3/8-16			

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm.

IMPORTANT: Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.

HUSQVARNA ROTARY LAWN MOWER - - MODEL NUMBER 917.375820



HUSQVARNA ROTARY LAWN MOWER - - MODEL NUMBER 917.375820

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	404142	Drive Control Assembly (Includes Cable)	36	191636	Gearcase Assembly, Complete
2	195745	Cover, Drive Control, Top	38	73800400	Locknut, Hex 1/4-20
3	187353	Pulley	40	192849	Spring
4	190039	Lever, Drive Control	41	195107	Kit, Wheel Adjuster, RH (Includes Knob and Bearing)
5	195744	Cover, Drive Control, Bottom			
6	186198	Screw, Torx Head #8 x 5/8	54	401189	Grassbag Assembly
7	400235X479	Mounting Bracket, Drive Control	55	86012	Driveshaft Cover
8	197195	Cable, Drive Control	57	189680	Frame, Grassbag
9	184987	Cap, Drive Control, Bottom	61	196886	Case, Upper
10	189074	Decal, Drive Control	62	197057	Shaft, Output
11	193912X460	Wheel & Tire Assembly	63	183508	Seal, Output Shaft
12	12000058	E-Ring	64	183511	Bushing
13	750003	Gear, Pinion	65	183509	Washer
14	189403	Dust Cover	66	183514	Seal, Worm Shaft
15	191017	Pawl, Drive	67	183506	Bearing, Ball
16	67725	Washer, Flat 3/8	68	183499	Gear, 27 Teeth
17	191039	Bearing, Wheel Adjuster	69	196884	Fixed Dog Clutch
18	196401	Selector Knob	70	183505	Wireform
23	88652	Screw 1/4-20 x 1-1/4	71	196883	Movable Dog Clutch
24	191730	Nut, Hex	72	196882	Fork
25	197163X479	Belt Guide Bracket	73	183513	Screw, Case
26	192325	Screw	74	196881	Case, Lower
27	175262	Pan Head Tapping Screw #10-24 x 2-3/4	75	196880	Seal, Lever
28	194407X418	Drive Cover	76	196879	Lever
29	83923	Locknut, Hex	77	196878	Screw, Lever
32	194018	Drive Pulley	78	196877	Spring
33	196857	V-Belt	79	183502	Shaft, Worm
35	195110	Kit, Wheel Adjuster, LH (Includes Knob and Bearing)			

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm.

IMPORTANT: Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.