



Air Compressor Diagram



Compressor Pump Diagram



Parts List

KEY NO.	PART NUMBER	DESCRIPTION
1	SSV-6	Globe Valve
2	CAC-4337-1	Check Valve
3	ABP-4900	Two-Stage Pump
4	BT-226	Belt
5	AC-0434	Outside Belt Guard
6	AC-0433	Inside Belt Guard
7	CAC-1004-2	Belt Guard Bracket
8	CAC-1359	Outlet Tube
9	CAC-1358	Pressure Relief Tube
11	CAC-1355	Manifold
12	DAC-278-1	Pressure Switch
14	SUDL-65	Motor Shaft Key
18	MO-6418	Motor
19	SS-559	Set Screw – 5/16 - 18 x 3/8
20	C-PU-2887	Pulley
21	SS-00403	Flywheel Direction Label
22	SS-2707	Drain Valve
24	SSF-3159	Screw 3/8 – 16 x 2 Hex Washer Head
25	SSF-3122-ZN	Screw 5/16 – 18 x 3/4 Whiz Lock Hex
26	SSF-8131	Speed Nut
27	SSF-8150	Lock Nut
28	SSF-953-ZN	Screw Self Tapping 10 x 5/8
29	91895680	Screw 1/4 – 20 x .75
31	SS-8553	Connector Body
33	TA-4412	Tank 60 gallon
36	TIA-4200	Safety Valve
37	SSP-7811	Nut Sleeve Assembly 1/4"
39	GA-360	Gauge
40	SSP-7812	Nut Sleeve Assembly 1/2" (2 used)

Parts List

KEY NO.	PART NUMBER	DESCRIPTION
1	KK-5039	Hardware Kit
2	ABP-4961400	Head
3	ABP-4950055	Gasket Kit
4	ABP-9053201	Drain Extension
5	ABP-4000100	Flywheel
6	ABP-9022001	Sight Glass Assembly
7	ABP-4940050	Valve Plate Kit
8	ABP-9101164	Drain Plug Screw
9	ABP-9162030	Drain Plug Seal
10	ABP-9004008	Flywheel Washer
11	ABP-9110012	Flywheel Screw
12	ABP-9163010	Craftshaft Seal
13	ABP-9013011	Shell Bearings (1 set)
* 14	ABP-8226504	HP Running Gear Kit
* 15	ABP-8226505	LP Running Gear Kit
16	ABP-4623050	HP Ring Kit
17	ABP-4924050	LP Ring Kit
18	ABP-4662000	Intercooler
19	ABP-4981000	Filter Replacement Kit (includes one #20)
20	ABP-4981100	Replacement Filter
21	ABP-9024014	Oil Fill Plug
		<u>Not Shown</u>
	M-176500	Parts Manual
	MG-OILSTAT	General Manual

*Includes rings, piston pin, snap rings, oil dipper and split bearings.