





## Parts Breakdown

9514B

*Products with multiple versions are listed in subsiding order with the newest version on top not indented*

<u>Fig #</u>	<u>Part ID</u>	<u>Part Name</u>	<u>Quantity</u>
1	226708-0	SPIRAL BEVEL GEAR 11, N9514B	1
2	211061-7	B. BEARING 6000LLB, 6222DWE	1
2	211063-3	B. BEARING 6000LB, 906H	1
3	241898-8	FAN 52, 9514B	1
4	517066-8	ARMATURE ASSEMBLY, N9514B	1
4	517066-8	ARMATURE ASSEMBLY, N9514B	1
5	210025-8	BALL BEARING 627LLB, 4324	1
5	211026-9	B. BEARING 627LLB, N9514B	1
6	633261-3	FIELD, N9514B	1
7	191914-5	CARBON BRUSH 70, N9514B	1
7	194970-4	CARBON BRUSH SET CB-70, N9514B	1
8	632072-3	BRUSH RING, /N9514B	1
9	265875-6	TAPPING SCREW BT4X25, N1900B	6
10	183370-3	HOUSING SET, 9514B	1
10	183577-1	HOUSING SET,9514B	1
10	183577-1	HOUSING SET,9514B	1
11	855990-0	NAME PLATE, 9514B	1
12	183370-3	HOUSING SET, 9514B	1
12	183577-1	HOUSING SET,9514B	1
12	183577-1	HOUSING SET,9514B	1
13	651514-8	SWITCH, 5007FK	1
13	651514-8	SWITCH, 5007FK	1
14	660065-0	CORD, 6406	1
16	231223-1	COMP. SPRING 6, N9514B	1
17	415562-9	SWITCH LEVER, N9514B	1
18	931202-6	HEX NUT M5, HR2410	1
23	212044-0	NEEDLE BEARING 810, 3901	1
24	213105-9	O RING 11, HP2010N	1
26	226709-8	SPIRAL BEVEL GEAR 36, 3901	1
27	211087-9	B. BEARING 6200DDW, JR3000V	1
29	322655-4	SPINDLE	1
30	342554-4	4 WHEEL COVER, N9514B	1
31	911231-5	P.H. SCREW M5X20, HR4002	2
32	224291-1	INNER FLANGE, N9501B	1
32	224376-3	INNER FLANGE 35,N9501B	1
33	911211-1	P.H. SCREW M5X12, HM1500B	1
34	224545-6	LOCK NUT 10-35, N9501B	1
34	224567-6	LOCK NUT, 9501B	1
34	224573-1	LOCK NUT 10-35, 9553NB	1
35	652638-3	OVER CURRENT RELAY, N9514B	1
36	423197-2	SPONGE SHEET, N9514B	1
400	781007-2	SPANNER, N9514B	1
401	782401-1	LOCK NUT WRENCH, N9514B	1
904	164329-9	GRIP HOLDER, N9514B	1
906	794043-9	DEPRESS CENTER WHEEL, 9501BZ	1
907	152487-3	GRIP 36, 9523NB	1
907	153489-2	GRIP 36, 9557NB	1
908	324130-6	N/A	1