

Parts List for 9739 Type 1

Item Number	Part Number	Description	Qty Required
1	898877	ARMATURE	1
2	886063	120V FIELD	1
3	874289	BRUSH & RETAINER ASY	2
3	865323	BRUSH HOLDER	2
3	865321	BRUSH INSULATOR	2
4	000000-00	No Longer Available	1
5	330072-97	CORD/10 FT/18-2	1
11	855284	BEARING	3
11	330003-17	BEARING,BALL	3
15	883095	BEARING	3
31	879401	GEAR	1
40	N074353	RECIP-SHAFT KIT	1
52	912305	HOUSING	1
57	000000-00	No Longer Available	1
81	897774	COLLAR	1
100	695077	MOUNTING BRKET TRIAC	1
101	690673	WIRE TIE	1
107	882703	SCREW	10
108	879415	INSULATOR BOOT	1
114	694432	BEARING MOUNT	1
121	882704	SCREW	10
125	879421	SCREW	10
130	879414	INTERMEDIATE PLATE	1
131	882187	SCREW	10
132	847418	SPRING	10
133	000000-00	No Longer Available	1
136	880988	KNOB	1

Parts List for 9739 Type 1

Item Number	Part Number	Description	Qty Required
138	879458	PLATE	1
141	883097SV	DRIVE SHAFT	1
142	684931	WASHER	10
143	890819	WOBBLE PLATE	1
147	802302	RING	10
148	879429	SPACER	10
150	883098	TUBE-CARRIER	1
153	882348	FELT SEAL	1
158	879423	FRONT HOUSING	1
159	879457	FELT SEAL	1
161	891672SV	SHOE & BRACKET ASSY.	1
163	849235	SCREW	10
165	879463	SCREW	10
172	882185	SCREW MACHINE STEEL	10
179	900826	SCREW	10
181	900826	SCREW	10
187	892440	SET SCREW	10
188	880952	PLUG	1
190	853246	RING	10
196	882255	SCREW	10
197	648924-00	SPRING	10
198	884696	RETAINER KIT	1
199	648594-00	CLAMP PIN	10
200	881937	SCREW & WASHER	10
201	880994	FELT WASHER	10
203	902998	SEAL	1
206	682063	CONNECTOR VS	1

Parts List for 9739 Type 1

Item Number	Part Number	Description	Qty Required
216	901266	STRAIN RELIEVER	1
217	802905	ALLEN WRENCH	1
218	842323	WRENCH HOLDER	1
230	5140061-28	GREASE	1
231	5140061-28	GREASE	1
861	000000-00	No Longer Available	1