



Parts List for 9748 Type 1

Item Number	Part Number	Description	Qty Required
1	898877	ARMATURE	1
2	898876	FIELD	1
3	874289	BRUSH & RETAINER ASY	2
4	5140096-04	SWITCH KIT	1
5	330081-08	CORD, 16-2SJ	1
8	882704	SCREW	2
11	855284	BEARING	2
12	802302	RING	2
14	879421	SCREW	1
15	906952	SCREW	2
16	911450SV	SS/A-SHOE ASSEMBLY	1
17	906725	INSULATOR BOOT	1
18	906701	FRONT HOUSING	1
19	879429	SPACER	1
20	853246	RING	1
21	890819	WOBBLE PLATE	1
27	883098	TUBE-CARRIER	1
29	879408	SCREW	2
30	882255	SCREW	2
31	648924-00	SPRING	1
33	897774	COLLAR	1
34	648594-00	CLAMP PIN	1
35	907449	ORBIT SELECTOR	1
36	882187	SCREW	3
37	847418	SPRING	1
39	879458	PLATE	1
40	879457	FELT SEAL	1

Parts List for 9748 Type 1

Item Number	Part Number	Description	Qty Required
41	684931	WASHER	1
42	902998	SEAL	1
44	330019-19	SCREW	4
45	906705	INTERMEDIATE PLATE	1
46	883097SV	DRIVE SHAFT	1
47	900826	SCREW	10
48	882703	SCREW	4
49	695077	MOUNTING BRKET TRIAC	1
50	690673	WIRE TIE	1
52	906945	MOTOR HOUSING	1
53	846249	NUT	1
56	906043	PLATE	1
57	906913	SET-HANDLE	1
58	697965	RET RING	1
59	882348	FELT SEAL	1
63	694432	BEARING MOUNT	1
65	801852	SEAL	1
71	908873	FELT SEAL	1
72	651021-00	SHOE LEVER	1
79	878904	FAN	1
82	638557-00	SPIRAL PIN	1
83	A12315	ID LABEL	1
84	638607-00	NAMEPLATE	1
87	865321	BRUSH INSULATOR	2
88	865323	BRUSH HOLDER	2
89	901266	STRAIN RELIEVER	1
90	330003-17	BEARING,BALL	1

Parts List for 9748 Type 1

Item Number	Part Number	Description	Qty Required
91	879431	BEARING-BALL	3
92	879401	GEAR	1
93	N074353	RECIP-SHAFT KIT	1
800	875667	LUBRICANT-4LBS	1
800	875914	TUBE GREASE	1
861	906962	CARRYING CASE	1