


## Parts Breakdown for the 22-44 Plus Infeed and Outfeed Table



Index No.	Part No.	Description	Size	Qty.
1.....	2244PLUS-501.....	Table .....		2
2.....	2244PLUS-502.....	Base Bracket .....		2
3.....	TS-0060051 .....	Hex Head Cap Screw .....	3/8"-16UNC x 1".....	4
4.....	TS-0680041 .....	Flat Washer .....	3/8".....	4
5.....	2244PLUS-505.....	Carriage Bolt.....	1/4"-20UNC x 3/4" .....	8
6.....	TS-0680021 .....	Flat Washer .....	1/4".....	8
7.....	TS-0561011 .....	Hex Nut .....	1/4".....	8