



Replacement Parts

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1	Cannot Furnish	Dust Chute	51	Cannot Furnish	Idler Hinge Bracket, Incl:
2	Cannot Furnish	Deflector - Lower	52	901-04-150-0206	5/16-18 X 5/16" SHSS
3	Cannot Furnish	Deflector - Upper	53	Cannot Furnish	Lock Nut
4	Cannot Furnish	Bearing Holder	54	905-04-071-3116	Pin
6	926-01-991-6317	2-1/2" Dia. Pulley, Incl:	55	904-01-010-1607	Washer
7	901-04-190-0201	5/16-18 X 5/16" SHSS	56	904-10-991-2051	Collar, Incl:
8	Cannot Furnish	Drive Pulley	57	901-04-150-0208	1/4-20 X 1/4" SHSS
9	904-01-031-4965	Washer	58	904-02-020-1708	7/16" Lockwasher
10	Cannot Furnish	Bevel Washer	59	902-01-040-1004	7/16"-14 Hex Nut
11	904-01-031-2926	Washer	60	Cannot Furnish	Base
12	901-02-010-0562	#10-32 X 5/16" RHS	61	420-01-079-0001	Bearing Retainer
13	901-02-010-0553	#6-32 X 1/2" RHS	62	420-01-406-0001	Shaft w/Collar
14	901-01-060-0640	3/8-16 X 3/4" HHCS	63	412-01-031-5002	Cover Plate
15	901-03-010-0770	5/16-18 X 1-1/4" SHCS	64	904-01-031-2905	Washer
16	904-02-010-1726	#8 Lockwasher	65	931-04-051-4072	Ball Crank
17	920-08-040-5344	Bearing	66	901-02-010-0558	#8-32 X 1/4" Rd. HS
18	928-07-010-7355	Bearing Spring	67	901-01-060-0625	7/16-14 X 2-1/4" HHCS
20	416-02-091-0001	Table	68	901-01-060-0642	3/8-16 X 1" HHCS
21	416-02-095-0001	Trunnion	69	904-02-020-1704	3/8" Lockwasher
22	416-02-395-0001	Trunnion, Incl:	70	927-01-010-2601	Woodruff Key
23	951-02-010-7820	Scale	71	901-04-140-6231	5/16-18 X 1/2" SHSS
24	901-06-450-2252	#2 X 3/16" Drive Screw	72	420-01-339-0001	Sanding Disc., Incl:
25	901-01-060-0612	1/4-20 X 5/8" HHCS	73	901-04-190-0201	5/16-18 X 5/16" SHSS
26	904-01-010-1603	Washer	74	901-03-030-0761	1/4-20 X 1/2" Fl. HHS
30	Cannot Furnish	Platen, Incl:	75	420-01-379-0001	Retainer, Incl:
31	420-01-011-0001	Stud	76	901-04-160-0283	5/16-18 X 1/2" SHSS
32	905-01-010-6714	5/32 X 1/4" Roll Pin	78	416-02-054-0001	Upper Guard
33	Cannot Furnish	Backstop	79	416-02-054-0002	Lower Guard
34	902-01-100-1028	1/2"-13 Hex Nut	80	901-04-121-3603	#8-32 X 5/16" Hdls. SS
35	904-01-010-1636	Washer	81	901-02-010-0560	#10-32 X 7/16" RHS
36	904-02-020-1705	1/2" Lockwasher	82	416-02-327-0002	Trunnion Clamp
37	901-01-060-3109	1/2-13 X 2-1/2" HHCS	83	901-07-261-3212	Stud
38	Cannot Furnish	Guard	84	904-01-031-2925	Washer
39	901-02-010-7502	3/8-16 X 1" RHS	85	931-03-011-4097	Star Wheel
40	Cannot Furnish	Bracket	86	928-01-021-4125	Spring
41	Cannot Furnish	Bracket	87	402-05-075-5001	Pointer
42	420-01-112-0002	Screw	88	901-02-010-0502	1/4-20 X 1/4" RHS
43	420-01-411-0001	Adj. Scr. w/Handknob	90	48245	Hex Soc. Wrench
44	420-01-412-0002	Adj. Scr. w/Handknob	91	49-340	V-Belt
45	902-02-050-1326	Special Nut	92	41-054	Motor Pulley, Incl:
46	Cannot Furnish	Idler Drum Ass'y., Incl:	93	901-04-190-0201	5/16-18 X 5/16" SHSS
47	Cannot Furnish	Collar, Incl:	*	31-427	Sanding Disc.
48	901-04-150-1185	1/4-20 X 5/16" SS	*	31-652	Abrasive Belt, 52-1/2" Long
49	905-04-071-3115	Pin			
50	920-04-021-4948	Bearing	*	NOT SHOWN	