


RYOBI 4V CHARGER – MODEL NO. AP4700

The model number will be found on a label attached to the housing. Always mention the model number in all correspondence regarding your **4V CHARGER** or when ordering replacement parts.



PARTS LIST

| KEY NO. | PART NUMBER | DESCRIPTION | QTY. | KEY NO. | PART NUMBER | DESCRIPTION | QTY. |
|---------|-------------|--------------------|------|-------------------|-------------|-------------------------|------|
| 1 | 140129001 | Charger..... | 1 | NOT SHOWN: | | | |
| 2 | 940221025 | Warning Label..... | 1 | | 987000654 | Operator's Manual | 1 |
| 3 | 940976383 | Data Label | 1 | | | | |

6-19-09
(REV:00)