


RYOBI 4V CHARGER – MODEL NO. AP4800

The model number will be found on a label attached to the housing. Always mention the model number in all correspondence regarding your **4V CHARGER** or when ordering parts.



PARTS LIST

KEY NO.	PART NUMBER	DESCRIPTION	QTY.	KEY NO.	PART NUMBER	DESCRIPTION	QTY.
1	140132001	Charger.....	1	NOT SHOWN:			
2	940221155	Warning Label.....	1	987000820	Operator's Manual	1	
3	940032112	Data Label	1	5-06-10			
4	940221156	Cord Tag Label	1	(REV:01)			