



BOSCH

Lawn Edge Trimmer

ART 26 EASYTRIM ACCU | 3 600 H78 J80

Table of Content

Spare parts list.....	2
Illustration - Type.....	3


Spare parts list

Item	Part Number	Description	Illu
2/2	F 016 L71 161	Adapter	
37	F 016 L71 360	Knife Guard Ø 260 MM	
38	1 619 X08 505	Cutting Disc	
839	1 619 X04 549	Blade	
852	1 617 S00 04W	Accumulator Battery 14,4V, 1,5Ah, NiCd	
853	2 607 224 727	Fast Charger CN 220/7,2-14,4V, 1h	
899	0 600 878 J80	Lawn Edge Trimmer 14,4V	

Illustration - Type - E

3 600 H78 H06
Stand 10-02
Issue 09-07-03

Fig./Abb. 1



Änderungen vorbehalten
Modifications reserved
Modifications réservées
Salvo modificaciones