




862



871



866



www.bosch.com

Parts List for BDGL14K-2 Type 1

Item Number	Part Number	Description	Qty Required
1	149518-01	SCREW	1
2	419233-10	KEYLESS CHUCK	1
3	90510100	GEARBOX ASSY	1
4	90506606	CLAMSHELL SET	1
5	90501711	BRAND LABEL	1
6	90510102	MOTOR&PINION	1
7	90503048	REAR COVER	1
8	90510104	VSR SWITCH	1
9	90503047	F/R ACTUATOR	1
10	90502969	GEL GRIP	1
11	90505069	SPRING PIN	1
12	5102250-00	SCREW	1
13	5145496-00	SPRING	2
14	000000-00	No Longer Available	1
15	148354-03	BIT CLIP	1
16	419581-01	BIT	1
17	90501718	NAMEPLATE	1
18	5146421-00	SCREW	1
19	497283-02	SCREW	2
20	311993-00	SCREW	4
21	5106167-00	SCREW	2
862	90505262	TOOL BAG	1
866	HPB14	BATTERY	2
867	5102026-00	BATTERY CAP	1
871	5103069-09	CHARGER ASSY.	1