



Parts List for BH200-AR Type 3

Item Number	Part Number	Description	Qty Required
1	185692-03	ARMATURE	1
2	575254-01	FIELD	1
3	185679-01	SWITCH, V.S.R.	1
4	832998-06	BRUSH	2
5	184545-25	CORD	1
6	187163-07	NAME PLATE	1
7	186188-00	CLAMSELL SET	1
9	183492-00	CHUCK KEY	1
10	330033-15	CHUCK,10MM	1
11	821986-00	SPRING	1
12	185662-00	BUSHING	1
13	186942-00	SPINDLE	1
14	185659-00	GEAR	1
16	185701-00	PLATE	2
17	185698-00	LEVER	1
18	186452-00	THRUST PLATE	1
19	185695-00	BEARING BLOCK	1
20	330019-04	SCREW,PLASTITE	7
21	186181-00	LABEL	1
22	186159-00	SPRING	2
23	185696-01	BRUSH RING	1
24	148814-00	BEARING	1
25	185702-00	HANDLE CAP	1
27	185396-01	LEAD	1
29	185396-03	LEAD	1
30	185396-04	LEAD	1
31	185396-05	LEAD	1

Parts List for BH200-AR Type 3

Item Number	Part Number	Description	Qty Required
32	185396-06	LEAD	1
33	185396-07	LEAD	1
34	185559-00	SIDE HANDLE	1
35	808401-00	DEPTH STOP	1