



## Parts List for BH90-B2 Type 1

Item Number	Part Number	Description	Qty Required
1	185692-01	ARMATURE	1
2	575254-01	FIELD	1
3	186438-01	SWITCH	1
4	832998-06	BRUSH	2
5	184545-23	CORD	1
6	000000-00	No Longer Available	1
7	186188-01	CLAMSELL SET	1
8	186188-01	CLAMSELL SET	1
9	183492-00	CHUCK KEY	1
10	187428-00	SERVICE KIT	1
11	821986-00	SPRING	1
12	185662-00	BUSHING	1
13	187428-00	SERVICE KIT	1
14	185659-00	GEAR	1
15	577796-00	BALL	1
16	185701-00	PLATE	2
17	185698-01	LEVER	1
18	186452-00	THRUST PLATE	1
19	185695-01	BEARING BLOCK	1
20	330019-04	SCREW,PLASTITE	7
21	186181-00	LABEL	1
22	186159-00	SPRING	1
23	185696-00	BRUSH RING	1
24	148814-00	BEARING	1
25	185702-01	HANDLE CAP	1
26	770236-00	PROTECTOR,CORD	1
28	185396-02	LEAD	1

## Parts List for BH90-B2 Type 1

Item Number	Part Number	Description	Qty Required
29	185396-03	LEAD	1