



Model BHR202/Z Parts List

A = Standard Equipment

○ = Circuit Diagram

Fig.	Part No.	Description	Q'ty	Unit
1	286263-4	CAP 35	1	PC.
2	233940-9	RING SPRING 19	1	PC.
3	417629-9	CHUCK COVER	1	PC.
4	257241-1	RING 21	1	PC.
5	345187-4	GUIDE WASHER	1	PC.
6	233916-6	CONICAL COMP. SPRING 21-29	1	PC.
7	921923-8	HEX. BOLT M8X120	1	PC.
8	345280-4	HEX. WASHER	1	PC.
9	417630-4	GRIP BASE	1	PC.
10	158057-6	GRIP 36 COMPLETE	1	PC.
	C10 931402-8	HEX. NUT M8	1	PC.
13	162245-9	CHANGE LEVER	1	PC.
14	233459-8	COMPRESSION SPRING 3	1	PC.
15	419192-8	LOCK BUTTON	1	PC.
16	213278-8	O RING 17	1	PC.
17	158216-2	GEAR HOUSING COMPLETE	1	PC.
	C10 213965-9	OIL SEAL 25	1	PC.
18	266351-3	TAPPING SCREW 4X35	4	PC.
19	153290-5	NEEDLE BEARING COMPLETE	1	PC.
20	961017-7	STOP RING E-3	2	PC.
21	417796-0	GUIDE BASE	1	PC.
22	233344-5	COMPRESSION SPRING 4	2	PC.
23	163430-7	LOCK PLATE COMPLETE	1	PC.
24	266374-1	TAPPING SCREW 4X25	2	PC.
25	233929-7	RING SPRING 29	1	PC.
26	267791-8	WASHER 31	1	PC.
27	233401-9	COMPRESSION SPRING 32	1	PC.
28	227109-5	SPUR GEAR 51	1	PC.
29	216022-2	STEEL BALL 7.0	1	PC.
30	158574-6	TOOL HOLDER COMPLETE	1	PC.
31	267229-3	FLAT WASHER 28	1	PC.
32	331769-8	SLEEVE 9	1	PC.
33	324669-9	IMPACT BOLT	1	PC.
34	324402-9	RING 10	1	PC.
35	421955-0	CUSHION RING 13	1	PC.
36	324216-6	O RING CASE	1	PC.
37	213073-6	O RING 9	1	PC.
38	233917-4	RING SPRING 28	1	PC.
39	324214-0	STRIKER	1	PC.
40	213227-5	O RING 16	1	PC.
41	318132-2	PISTON CYLINDER	1	PC.
42	267104-3	FLAT WASHER 12	1	PC.
43	324215-8	PISTON JOINT	1	PC.
44	267104-3	FLAT WASHER 12	1	PC.
45	213727-5	O-RING 63	1	PC.
46	211012-0	BALL BEARING 606ZZ	1	PC.
47	961003-8	RETAINING RING S-7	1	PC.
48	233343-7	COMPRESSION SPRING 7	1	PC.

49	227179-4	SPUR GEAR 10	1	PC.
50	324668-1	CAM SHAFT	1	PC.
51	331768-0	CLUTCH CAM	1	PC.
52	219014-0	SWASH BEARING 10	1	PC.
53	226632-7	HELICAL GEAR 25	1	PC.
54	266273-7	HEX. SOCKET HEAD BOLT M4X12	2	PC.
55	345179-3	BEARING RETAINER	1	PC.
56	267234-0	FLAT WASHER 8	1	PC.
57	211032-4	BALL BEARING 608ZZ	1	PC.
58	324212-4	RING 8	1	PC.
59	961011-9	STOP RING E-4	1	PC.
60	941102-2	FLAT WASHER 5	1	PC.
61	233342-9	COMPRESSION SPRING 6	1	PC.
62	345363-0	CHANGE PLATE	1	PC.
63	158215-4	INNER HOUSING COMPLETE	1	PC.
64	443126-9	FELT	1	PC.
65	213407-3	O RING 26	1	PC.
66	213077-8	OIL SEAL 10	1	PC.
67	210059-1	BALL BEARING 6000DDW	1	PC.
68	267213-8	FLAT WASHER 10	1	PC.
69	240092-9	FAN 64	1	PC.
70	519226-8	ARMATURE ASSEMBLY 18V	1	
	D10	INC. 67-69,71,72		
71	253823-7	FLAT WASHER 7	1	PC.
72	210023-2	BALL BEARING 627DDW	1	PC.
73	267816-8	WAVE WASHER 15	1	
74	865285-3	BHR202 NAME PLATE 20MM	1	
75	188566-1	HOUSING SET	1	
	C10	810324-4	CAUTION LABEL	1
	D10	INC. 82		
76	638020-0	YOKE UNIT	1	PC.
77	643834-4	BRUSH HOLDER	1	
78	643835-2	BRUSH HOLDER	1	
79	266326-2	TAPPING SCREW 4X18	2	PC.
80	911006-2	PAN HEAD SCREW M3X8	1	PC.
81	689070-8	HEAT SINK	1	PC.
82	188566-1	HOUSING SET	1	
	C10	810324-4	CAUTION LABEL	1
	D10	INC. 75		
83	424128-4	HOLDER CAP COVER	2	
84	643829-7	HOLDER CAP	2	PC.
85	194435-6	CARBON BRUSH CB-441	1	PC.
86	424111-1	SWITCH COVER	1	
87	450615-7	F/R CHANGE LEVER	1	
88	650578-9	SWITCH TG553FSB-6	1	PC.
89	631792-6	LIGHT CIRCUIT	1	PC.
90	266326-2	TAPPING SCREW 4X18	7	PC.
91	643812-4	TERMINAL	1	PC.
92	188453-4	BATTERY HOUSING SET	1	SET
	C10	263005-3	RUBBER PIN 6	2
	D10	INC. 95		
93	263036-2	RUBBER PIN 5	1	PC.
94	268184-2	PIN 1.5	1	PC.
95	188453-4	BATTERY HOUSING SET	1	SET
	C10	263005-3	RUBBER PIN 6	2

	D10	INC. 92	
	96	266326-2	TAPPING SCREW 4X18
	97	424042-4	CUSHION RUBBER
	98	424026-2	CUSHION
	99	424042-4	CUSHION RUBBER
A	A01	324219-0	DEPTH GAUGE
	D01	652045-0	+PAN HEAD SCREW M3.5X5
		BHR202Z	TOOL ONLY
			2 PC.
			1 PC.
			1 PC.
			1 PC.
			1 PC.
			2 PC.