




SPARE PARTS LIST


SURFACE PREPARATION EQUIPMENT

BMG 555P, 2022-04

BMG 555P
FRAME, COMPLETE




Ref	Part No	Description	Remark	QTY KIT
1	533 08 84-01	CLUTCH	CLUTCH	1
2	533 36 95-01	BUSHING	BUSHING	1
3	533 46 29-01	SPROCKET	SPROCKET	1
4	533 39 50-01	ENGINE	ENGINE	1
5	533 13 15-01	BELT	BELT	1
6	533 28 85-01	MOUNTING BRACKET	MOUNTING BRACKET	1
7	533 73 08-01	BELT GUARD	BELT GUARD	1
8	534 08 61-01	BELT GUARD	BELT GUARD	1
9	535 10 51-01	BELT GUARD	BELT GUARD	1
10	535 19 12-01	MOUNTING BRACKET	MOUNTING BRACKET	1
11	533 95 59-01	TANK	TANK	1
12	533 59 60-01	ELECTRONIC BOX	ELECTRONIC BOX	2
13	533 34 33-01	SHAFT	SHAFT	2
14	533 70 99-01	RING	RING	2
15	533 00 75-01	WHEEL	WHEEL	2
16	533 23 60-01	PLATE	PLATE	2
17	535 02 54-01	DECAL	DECAL	2
18	535 22 76-01	FRAME	FRAME	1
19	533 24 88-01	SHAFT	SHAFT	4
20	533 64 30-01	BUSHING	BUSHING	2
21	533 24 33-01	SPRING	SPRING	2
22	533 29 75-01	BOLT	BOLT	2
23	533 35 69-01	FRAME	FRAME	1
24	533 31 42-01	BRACKET	BRACKET	1
25	533 40 06-01	STIFFENER	STIFFENER	1
26	535 67 67-01	SPACER	SPACER	1
27	533 75 10-01	LIGHT	LIGHT	1
28	535 96 26-01	KEY	KEY	1
29	535 14 65-01	CABLE	CABLE	1
30	535 14 66-01	CABLE	CABLE	1
31	533 72 20-01	WASHER	WASHER	1
32	533 60 46-01	WHEEL	WHEEL	2



Ref	Part No	Description	Remark	QTY KIT
1	535 19 12-01	MOUNTING BRACKET	MOUNTING BRACKET	1
2	534 02 41-01	SENSOR	SENSOR	1
3	533 36 94-01	SWITCH	SWITCH	1
4	533 38 29-01	STOP	STOP	1
5	533 71 35-01	IGNITION SWITCH	IGNITION SWITCH	1
6	533 82 90-01	METER	METER	1
7	533 45 37-01	CABLE	CABLE	1
8	535 21 07-01	FRAME	FRAME	1
9	535 24 75-01	HANDLE	HANDLE	1
10	533 88 94-01	SWITCH	SWITCH	1
11	533 27 61-01	SWITCH	SWITCH	1
12	533 76 77-01	PIPE CLAMP	PIPE CLAMP	1
13	533 37 16-01	LIGHT	LIGHT	4
14	533 40 81-01	BRACKET	BRACKET	1
15	534 76 86-01	PLUG	PLUG	1
16	533 23 41-01	KEY	KEY	1
17	533 42 91-01	PLATE	PLATE	1
18	533 95 87-01	PLATE	PLATE	1
19	533 28 09-01	HANDLE	HANDLE	1
20	535 23 09-01	STRIP	STRIP	1
21	533 23 82-01	WIRE	WIRE	1
22	533 37 62-01	HANDLE	HANDLE	1
23	533 23 89-01	SPRING	SPRING	1
24	533 23 95-01	EYE BOLT	EYE BOLT	1
25	533 23 37-01	SHAFT	SHAFT	1
26	533 28 71-01	SPRING	SPRING	2
27	533 22 59-01	SPRING	SPRING	2
28	536988901	TBD	BOX	1
29	533 78 12-01	BATTERY	BATTERY	1
30	536989001	TBD	BAR	1
31	533 28 91-01	KEY	KEY	1
32	533 76 25-01	UNIT	UNIT	1
33	534 07 63-01	SPACER	SPACER	2
34	533 35 23-01	STOP	STOP	1
35	533 94 62-01	SWITCH	SWITCH	1
36	533 40 36-01	STOP	STOP	1

BMG 555P
WATER TANK ASSEMBLY




WATER TANK

BMG 555P, 2022-04

Ref	Part No	Description	Remark	QTY KIT
1	533 21 91-01	TANK	TANK	1
2	533 36 93-01	MOUNT	MOUNT	1
3	533 25 34-01	TANK	TANK	1
4	533 38 73-01	BUSHING	BUSHING	1
5	533 34 58-01	TANK	TANK	1
6	533 38 79-01	FITTINGS	FITTINGS	1
7	533 39 69-01	GASKET	GASKET	2
8	533 37 95-01	HOSE	HOSE	1
9	533 21 69-01	TANK	TANK	4

BMG 555P
HEAD ASSEMBLY




GRINDING HEAD

BMG 555P, 2022-04

Ref	Part No	Description	Remark	QTY KIT
42	534 88 85-01	BRUSH	BRUSH	1
43	534 69 27-01	CAP	CAP	4
44	533 75 28-01	SEAL	SEAL	1
45	533 50 25-01	STRIP	STRIP	1
46	533 42 23-01	SHROUD	SHROUD	1
47	900 00 00-02	DUMMY PART	DUMMY PART	1
48	533 65 32-01	PROTECTIVE COVER	PROTECTIVE COVER	1
49	533 26 76-01	BUMPER	BUMPER	1
50	533 02 71-01	HOLDER	HOLDER	2
51	533 34 40-01	CIRCLIP	CIRCLIP	1
52	533 22 05-01	RING	RING	2
53	533 01 85-01	MOTOR	MOTOR	1
54	534 57 52-01	BLOCK	BLOCK	1
54	535 91 34-01	BLOCK	BLOCK	2
56	535 37 86-01	CLUTCH	CLUTCH	1
57	535 34 32-01	COUPLING	COUPLING	1
58	533 21 85-01	BEARING	BEARING	1
59	534 69 90-01	PULLEY	PULLEY	1
60	533 37 11-01	RING	RING	1
61	535 35 75-01	BEARING	BEARING	1
62	534 38 63-01	BEARING HOUSING	BEARING HOUSING	1
63	533 61 61-01	POLY-V BELT	POLY-V BELT	1

BMG 555P
UPPER & LOWER DRIVE SYSTEM




DRIVE UNIT

BMG 555P, 2022-04

Ref	Part No	Description	Remark	QTY KIT
64	535 08 65-01	PLATE	PLATE	2
65	535 08 66-01	PLATE	PLATE	1
66	535 22 65-01	PLUG	PLUG	3
67	533 37 57-01	SEAL	SEAL	1
68	533 04 32-01	HOUSING	HOUSING	1
69	533 50 30-01	PULLEY	PULLEY	1
70	534 41 53-01	COVER	COVER	1
71	535 15 79-01	PLATE	PLATE	1
72	533 66 24-01	PULLEY	PULLEY	1
73	535 91 35-01	PLATE	PLATE	1
74	533 41 34-01	PULLEY	PULLEY	3
75	535 25 40-01	RING	RING	1
76	533 54 57-01	PULLEY	PULLEY	1
77	533 06 22-01	RING	RING	1
78	534 06 93-01	BELT	BELT	1
79	535 20 98-01	PLATE	PLATE	1
80	533 45 96-01	COVER	COVER	2
81	533 70 69-01	SEAL	SEAL	3
82	535 15 44-01	COVER	COVER	1
83	534 76 28-01	PLATE	PLATE	3

BMG 555P
TENSION PULLEY ASSEMBLY




PULLEY

BMG 555P, 2022-04

Ref	Part No	Description	Remark	QTY KIT
84	533 11 97-01	PULLEY	PULLEY	1
85	533 72 29-01	RETAINER RING	RETAINER RING	1
86	533 72 28-01	RETAINER RING	RETAINER RING	2
87	533 11 11-01	BEARING	BEARING	2
88	535 25 39-01	AXLE	AXLE	1

BMG 555P
TENSION PULLEY ASSEMBLY




PULLEY ASSY

BMG 555P, 2022-04

Ref	Part No	Description	Remark	QTY KIT
89	900 00 00-02	DUMMY PART	DUMMY PART	1
90	533 06 35-01	PULLEY	PULLEY	1
91	900 00 00-02	DUMMY PART	DUMMY PART	1
92	533 91 42-01	RETAINER RING	RETAINER RING	3
93	533 21 83-01	CIRCLIP	CIRCLIP	2
94	900 00 00-02	DUMMY PART	DUMMY PART	2
95	533 36 61-01	AXLE	AXLE	1
96	533 29 34-01	KEY	KEY	1
97	535 09 57-01	BEARING HOUSING	BEARING HOUSING	1
98	535 36 39-01	PULLEY	PULLEY	1
99	533 10 96-01	LOCK	LOCK	1

BMG 555P
DRIVE PULLEY




DRIVING PULLEY

BMG 555P, 2022-04

Ref	Part No	Description	Remark	QTY KIT
100	533 90 54-01	HEX KEY	HEX KEY	1
101	535 14 79-01	AXLE	AXLE	1
102	533 37 41-01	KEY	KEY	1
103	533 25 97-01	BUSHING	BUSHING	1
104	535 65 40-01	UNIT	UNIT	1
105	533 29 22-01	RETAINER RING	RETAINER RING	1
106	535 09 43-01	HOUSING	HOUSING	1
107	533 70 37-01	BEARING	BEARING	1
108	533 33 28-01	CIRCLIP	CIRCLIP	1

BMG 555P
PULLEY



PULLEY

BMG 555P, 2022-04

Ref	Part No	Description	Remark	QTY KIT
109	533 33 28-01	CIRCLIP	CIRCLIP	3
110	533 29 22-01	RETAINER RING	RETAINER RING	3
111	533 79 44-01	BEARING	BEARING	2
112	535 09 51-01	BEARING HOUSING	BEARING HOUSING	1
113	533 60 59-01	BUSHING	BUSHING	1
114	535 36 39-01	PULLEY	PULLEY	1
115	533 24 78-01	BEARING HOUSING	BEARING HOUSING	1
116	534 30 28-01	AXLE	AXLE	1
117	533 90 54-01	HEX KEY	HEX KEY	1