





## Parts Breakdown

**BO5020**

*Products with multiple versions are listed in subsiding order with the newest version on top not indented*

<u>Fig #</u>	<u>Part ID</u>	<u>Part Name</u>	<u>Quantity</u>
1	183107-8	HOUSING SET, BO5020	1
2	682502-4	CORD GUARD 8-85, HP2010N	1
3	664002-6	CORD	1
4	687063-9	STRAIN RELIEF, 4323K	1
5	265995-6	TAPPING SCREW 4X18, 4323K	2
7	651286-5	SWITCH, BO5021	1
8	643552-4	BRUSH HOLDER, BO5012K	2
9	191956-9	CARBON BRUSH 75, JR3000V	1
9	194971-2	CARBON BRUSH SET CB-75, JR3000V	1
12	210017-7	BALL BEARING 607DDW, 420S,T2	1
13	313080-0	COUNTER WEIGHT, BO5010	1
14	633431-4	FIELD 115V, BO5021K	1
15	265995-6	TAPPING SCREW 4X18, 4323K	8
16	851741-9	NAME PLATE, BO5020	1
17	183107-8	HOUSING SET, BO5020	1
18	252045-6	SQUARE NUT M5, BO5021K	1
19	168324-1	FRONT GRIP, BO5021K	1
20	517231-9	ARMATURE ASS'Y 115V, BO5010	1
21	961015-1	STOP RING E-9, BO5021	1
22	210020-8	BALL BEARING 6000DDU, BO5010	1
23	241896-2	FAN 88, BO5010	1
24	253315-6	THIN WASHER 15, UM401DW	1
25	151517-7	DUST BAG COMPLETE, BO5021K	1
26	151518-5	DUST NOZZLE COMPLETE, BO5021K	1
27	265995-6	TAPPING SCREW 4X18, 4323K	2
28	183088-6	SKIRT SET, B05010,T2	1
29	183088-6	SKIRT SET, B05010,T2	1
30	316835-2	BEARING BOX, BO5010	1
31	211227-9	B. BEARING 6002DDW,9015A	1
31	211236-8	BALL BEARING 6002DDW,BO5001	1
32	253739-6	FLAT WASHER 4, BO5010	1
33	911116-5	P.H. SCREW M4X12, 4301BV	1
34	416062-2	BRAKE RING, BO5010	1
34	421866-9	BRAKE RING, BO5010	1
35	316834-4	BEARING BOX COVER, BO5010	1
36	743051-7	BASE/PAD, BO5010	1
36	743051-7	BASE/PAD, BO5010	1
36	743081-8	BASE/PAD , BO5010	1
36	743081-8	BASE/PAD , BO5010	1
37	911128-8	P.H. SCREW M4X16, 1902	3
1,001	794544-7	ABRASIVE DISC 125#120, BO5001	1
1,002	183782-0	PLASTIC TOOL CASE, BO4552K	1
1,002	824562-2	PLASTIC TOOL CASE, BO5021K	1
1,002	824562-2	PLASTIC TOOL CASE, BO5021K	1