





Parts List for BTFP02028 Type 1

Item Number	Part Number	Description	Qty Required
49	AB-9038911	SHROUD	1
102	AB-9042032	WHEEL	2
103	AB-9038066	FOOT	1
105	AB-9048102	CHECK VALVE	1
106	AB-9047061	QUICK COUPLING	1
107	AB-9047062	TAP BALL VALVE	1
108	AB-9051209	REGULATOR	1
109	AB-9052135	GAUGE	1
110	AB-9049115	SAFETY VALVE	1
112	AB-9050600	ELBOW	1
114	AB-9414958	SHOULDER BOLT	2
116	AB-9038352	PLUG	2
127	AB-9270046	TUBING	1
131	AB-9063096	PRESS.SW.4W 3/8IN VA	1
132	AB-9412185	POWER CORD USA	1
145	AB-9043394	PIPE	1
200	AB-9416951	PUMP ASSEMBLY	1
202	AB-9415350	CYLINDER	1
203	AB-7161400	HEAD	1
204	AB-9415352	CRANKSHAFT	1
206	AB-0540051	VALVE PLATE ASSEMBLY	1
208	AB-910110	CONROD/PISTON	1
223	AB-7181110	AIR FILTER	1
226	AB-9415354	BELT	1
230	AB-9170097	BEARING	2
241	AB-610301	CONROD COVER	1
246	AB-9038351	FAN	1

Parts List for BTFP02028 Type 1

Item Number	Part Number	Description	Qty Required
250	AB-9101504	SCREW	4
251	AB-9103284	TORX SCREW	1
252	AB-9131640	WASHER	1
253	AB-9107241	SCREW	1
254	AB-9101174	SCREW M4X18	1
255	AB-9415414	MOTOR COVER	1
256	AB-9170113	BALL BEARING	1
257	AB-9014014	SPRING	1
258	AB-9114042	SCREW TC 4X10	1
262	AB-7350302	VALVE PLATE GASKET	1
264	AB-6750400	GASKET-PLATE HEAD	1
278	AB-9040012	SEAL	1
400	AB-9412036	NUT	2
401	98025-40	BOLT	1
402	AB-9122044	NUT-M8	1
403	AB-9412016	WASHER 8X24X2	2
404	AB-9134330	WASHER	1
405	AB-9414245	DOUBLE SCREW 3/8M-1/	1
406	AB-9050375	TURNING NUT 3/8IN	1
407	AB-9050376	CONNECTION 1/4IN	1
408	AB-9412518	SCREW PARKER 5X16	4
409	AB-9131654	WASHER	4
410	AB-9050372	ELBOW	1
411	AB-9101557	SCREW	4
412	AB-9131030	WASHER	4
413	AB-9142592	SCREW-PARKER AB 3.9X	3
414	AB-9414642	CABLE 3 POLES UL	1

Parts List for BTFP02028 Type 1

Item Number	Part Number	Description	Qty Required
500	AB-9052127	GAUGE	1
501	AB-9038575	GUARD	1
502	AB-9038951	ADAPTER	1
503	N282780	PERFORMANCE LABEL	1
504	N274721	SPEC. LABEL	1
505	N281939	WARNING LABEL	1
506	N018445	WARNING LABEL	1
507	N006525	WARNING LABEL	1
508	A17566	LABEL	1