


WIRING DIAGRAM



**IMPORTANT!** - To assure product SAFETY and RELIABILITY, repairs, maintenance or adjustments should be performed by MAKITA Service Centers or other qualified service organizations. Always use MAKITA replacement parts.

Fig.	Part NO.	Qty. Used	DESCRIPTION	Fig.	Part NO.	Qty. Used	DESCRIPTION
1	183256-1	1	HOUSING SET (Incl. Fig. 35)	23	267104-3	1	FLAT WASHER 12
3	417283-9	1	F/R CHANGE LEVER	24	152772-4	1	INTERNAL GEAR CASE CPL. (Incl. Fig. 31)
4	651998-0	1	SWITCH	25	216011-7	2	STEEL BALL 5.6
5	638016-1	1	TERMINAL UNIT (Incl. 2 Ea. Insulated TERMINAL RBV1.25-3 654037-5)	26	638019-5	1	ENDBELL COMPLETE (Incl. 2 Ea. RECEPTACLE 654069-2)
10	152661-3	1	HAMMER CASE COMPLETE	27	191975-5	1	CARBON BRUSH CB-431
11	911138-5	4	PAN HEAD SCREW M4X20	28	643933-2	2	BRUSH HOLDER CAP
12	267175-0	1	FLAT WASHER 24	29	619058-4	1	ARMATURE
14	324056-2	1	ANVIL	30	632966-2	1	YOKE UNIT
15	324033-4	1	HAMMER B	31	152772-4	1	INTERNAL GEAR CASE CPL. (Incl. Fig. 24)
16	216019-1	29	STEEL BALL 3	32	211136-2	1	BALL BEARING 6801LLB
17	261117-6	1	NYLON WASHER 12	33	689096-0	1	FET SPACER
18	233296-0	1	COMPRESSION SPRING 24	34	266170-7	1	TAPPING SCREW ST3X8
19	344907-3	1	SPRING HOLDER	35	183256-1	1	HOUSING SET (Incl. Fig. 1)
20	324051-2	1	SPINDLE B	37	911038-9	6	PAN HEAD SCREW M3X20
21	227009-9	2	SPUR GEAR 16	38	231964-9	1	RING SPRING 7
22	268064-2	2	PIN 3.5				

2 Model BTW070Z

04-01