


# C 342




**Accessory**

**954040503A**

# REPAIR PARTS / PIÈCES DE RECHANGE

GRASS CATCHER C342 - MODEL # 954040503A / RAMASSE-HERBE - NUMÉRO DE MODÈLE 954040503A



# REPAIR PARTS / PIÈCES DE RECHANGE

GRASS CATCHER C342 - MODEL # 954040503A / RAMASSE-HERBE - NUMÉRO DE MODÈLE 954040503A

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
2	532069180	Nut, Crownlock #10-24	29	817490508	Screw 5/16-18 x 1/2
3	532127533	Screen, Cover			Hex, Self Tapping
4	532134678	Cover	30	532131137	Pin, Support Post
5	532126840	Chute, Upper	31	532134496	Plug, Tubing End
6	818021008	Screw, Special #10-14x1/2			
7	532140572	Dump Bag Indicator	32	532134639	Bagger, Frame
8	532087175	Screw, #10-24 x 1-1/8	33	532128600	Pin, Hinge
9	819061216	Washer 3/16x3/4x16 Ga.	34	532127534	Gasket, Cover
10	532007206	Spacer, Split	35	532129585	Container, Top
11	532060867	Nut, Acorn #10-24	36	532129586	Container, Bottom
12	810071000	Washer, lock	37	532134637	Seal, Cover
13	532109808	Latch, Chute	38	532130895	Latch Handle, Cover
14	532125004	Nut, Weld			couverture
15	532130760	Latch, Hook	39	532155857	Strip, Reinforcement
16	532130759	Rubber, Latch	40	871141008	Screw #10-24 x 1/2
18	532162803	Chute, Lower	41	532156006	Bagger, Support Tube
20	871161010	Screw #10-24 x 5/8			gazon
21	532132796	Spring, Cover L.H. (black)	42	532145186	Reinforcement Plate
22	532133235	Spacer, Cover	43	819112410	Washer 11/32x1.5x10 Ga.
23	532132983	Spring, Cover R.H. (gray)	44	810040500	Washer, lock
24	532126813	Post, Support	45	532128638	Nut, Wing
25	532063124	Locknut 5/16 x 18	46	874760536	Bolt, Hex 5/16-18 x 2-1/4
26	532124670	Spring, Retainer	—	532104419	Bag, 3.0 mil. 30 Gallon
27	874760512	Bolt, Hex 5/16-18 x 3/4			gallonTrash (not included
28	532130889	Bracket, Mounting			with bagger)
			—	532155947	Owner's Manual
					Manuel de propriétaire