



Parts List for CD1200SK Type 1

Item Number	Part Number	Description	Qty Required
1	5104014-00	CLAMSHELL SET	1
2	311978-01	F/R ACTUATOR	1
3	148354-03	BIT CLIP	1
4	607918-41	SCREWDRIVER BIT	1
5	5104016-00	SWITCH	1
6	5100850-01	TRANSMISSION	1
7	5100926-09	MOTOR & PINION	1
8	330019-00	SCREW	6
9	419233-06	KEYLESS CHUCK	1
10	149518-01	SCREW	1
11	311975-01	TOP,INSERT	1
12	497039-84	NAMEPLATE	1
13	497017-21	ID LABEL	1
14	046376-00	PIN	1
15	311940-02	SCREW	2
861	5102001-09	KITBOX	1
866	FSB12	BATTERY	1
867	5102026-00	BATTERY CAP	1
871	90500928	CHARGER	1