



Parts List for CD121K-B3 Type 1

Item Number	Part Number	Description	Qty Required
1	5140024-79	SCREW	8
2	5140024-80	ENCLOSURE	1
3	5140024-81	SWITCH ASSY	1
4	5140024-82	BATTERY PACK	1
5	5140024-83	RING	1
6	5140024-84	SPRING	1
7	5140024-85	RING	1
8	5140024-86	RING	1
9	5140024-87	SPRING	1
10	5140024-88	HOLDER	1
11	5140024-89	SCREW	2
12	5140024-90	CHUCK	1
13	5140024-91	CHUCK SCREW	1
14	5140024-92	BALL GROUP	15
15	5140024-93	RING	1
16	5140024-94	RING	2
17	5140024-95	BALL GROUP	16
18	5140024-96	GOVERNOR BOX	1
19	5140024-97	SHAFT COAT	1
20	5140024-98	SHAFT	1
21	5140024-99	GEAR RING	1
22	5140025-73	GEAR	3
23	5140025-74	BRACKET	1
24	5140025-75	PLANET GEAR	3
25	5140025-76	WASHER	1
26	5140025-77	SCREW	2
27	5140025-78	FLANGE	1

Parts List for CD121K-B3 Type 1

Item Number	Part Number	Description	Qty Required
28	5140025-79	SCREW	1
29	5140025-80	MOTOR	1
31	5140025-82	SCREWDRIVER BIT	1
32	5140025-83	BIT CLIP	1
33	5140025-84	LEVER	1
34	5140025-98	BATTERY BASE SUPPORT	1
35	5140025-96	CHARGER	1