



Parts List for CD9600K Type 3

Item Number	Part Number	Description	Qty Required
1	486372-04	CLAMSHELL (SET)	1
2	311978-00	ACTUATOR	1
3	148354-03	BIT CLIP	1
4	607918-41	SCREWDRIVER BIT	1
5	497030-35	SWITCH	1
6	486256-36	MOTOR & GEARBOX	1
8	330013-03	SCREW	3
9	419233-06	KEYLESS CHUCK	1
10	149518-01	SCREW	1
11	497346-24	TOP INSERT	1
12	419868-08	NAMEPLATE	1
13	497017-26	ID LABEL	1
14	046376-00	PIN	1
15	330019-00	SCREW	3
861	499124-13	KIT BOX	1
866	PS120	9.6V BATTERY PACK	2
867	645221-00	BATTERY CAP	1
871	418352-00	PS150 9.6V CHARGER	1