


RYOBI 12 VOLT HYBRID SAW – MODEL NUMBER CR120L



Ref #	Part #	Description	Qty	Context	Note	Foot Note
1	270017124	SWITCH ASSEMBLY	1			
2	230008001	MOTOR ASSEMBLY	1			
3	200687001	HOUSING ASSEMBLY	1			
4	940304497	LOGO LABEL	1			
5	632340001	CLIP	1			
6	200729001	TRIGGER ASSEMBLY	1			
7	692102001	SPRING	1			
8	940976266	DATA LABEL	1			
9	660570004	SCREW (M3 x 14 mm)	8			
10	200728001	GEAR HOUSING ASSEMBLY	1			
11	200736001	BEVEL PINION ASSEMBLY	1			
12	200727001	BEVEL CASE SUPPORT ASSEMBLY	1			
13	660203055	SCREW (M3 x 14 mm)	4			
14	632473001	SHOE	1			
15	200726001	BEVEL GEAR ASSEMBLY	1			
16	660228016	SCREW (M3 x 8 mm)	2			
17	300019005	BUSHING ASSEMBLY w/BEARING	1			
18	661065001	SCREW (M3.5 x 10 mm)	2			
19	632475001	SAW BAR SLIDE BRACKET	1			
20	681261002	BEARING SLEEVE	1			
21	610766001	COVER PLATE	1			
22	681261001	FRONT BEARING SLEEVE	1			
23	632474001	CLIP PLATE	2			
24	902094001	FELT WASHER	1			
25	302482001	SAW BAR & BLADE CLAMP ASSEMBLY	1			
26	690227032	WOOD CUTTING BLADE	1			
27	690227053	METAL CUTTING BLADE	1			
	987000325	OPERATOR'S MANUAL (961022021)				