



Parts List for CS1014 Type 1

Item Number	Part Number	Description	Qty Required
1	90578859	GEAR CASE ASSY.	1
2	90568798	OUTPUT SPINDLE	1
3	90568897	TORSION SPRING	1
4	90568775	LOWER GUARD	1
5	90568898	SPRING CLIP	1
6	90568901	OUTER FLANGE	1
7	90578338	HEX SOC HD SCR	1
8	90570231	L GUARD LEVER	1
9	370748	SCREW	3
10	562160-07	SCREW	3
11	330024-13	MACHINE SCREW	1
12	90569118	RUBBER STOP	1
13	90569114	CARRIAGE BOLT	1
14	90578341	DOWEL PIN	1
15	90578384	E-CLIP	1
16	330024-39	MACHINE SCREW	3
17	90574987	RUBBER PLUG	1
20	90568779	MOTOR HOUSING	1
23	90568788	BRUSH HOLDER	2
24	90568794	BRUSH &SPRING	2
25	90568789	BRUSH CAP	2
26	330019-41	SCREW	2
27	90576757	NAME PLATE	1
28	90570940	ID LABEL	1
29	90568776	HANDLE ASSY.	1
30	90579269	SCREW	6
31	90568795	SWITCH	1

Parts List for CS1014 Type 1

Item Number	Part Number	Description	Qty Required
32	90576742	CORD SET	1
33	329301-00	CLAMP,CORD	1
34	90568797	CORD PROTECTOR	1
35	90579371	ALLEN WRENCH	1
36	90576473	SHOE ASSY.	1
37	90568912	WING SCREW	1
38	90580384	WASHER	2
39	90568910	WING NUT	1
40	330015-01	NUT,HEX	2
41	330024-09	SCREW	1
42	90568917	SCREW	1
43	90568918	COMPRESSION SPRING	1
44	90569115	LOCK NUT	1
45	90569116	RIVING KNIFE	1
46	90578352	E-CLIP	1
47	90568787	WRENCH	1
48	90568785	RIP FENCE	1