



H Husqvarna




CT20



Spare Parts
Pièces Détachées


Owner's Manual 601 00 24 63
Reference No. 711783

CULTIVATOR PARTS CT20 ENGINE ASSEMBLY




Note: Always use original equipment parts. Use of service/replacement parts other than original parts may void your warranty.

All unnumbered items are interchangeable with opposite side



REF. NO.	PART NO.	PART NAME
10	-	ENGINE, 2.0TEC (See Engine Manual)
11	601 00 06 17	WASHER, FLAT .378X1.25X.06
12	601 00 19 50	ROTOR (SMALLER DIA.)
13	601 00 00 14	WASHER, REGSPTLK.263X.49X.07
14	601 00 12 83	SCREW, 1/4-20X1.75 HHC
17	601 00 12 84	CABLE, THROTTLE, CULTIVATOR
	601 00 24 63	MANUAL, OWNERS

**CULTIVATOR PARTS CT20
TRANSMISSION REPAIR PARTS**




REF. NO.	PART NO.	PART NAME
300	531 30 96-74	TRANSMISSION ASSY.
310	601 00 22 56	BRKT,DEPTH FLAT/WIDE
311	601 00 00 69	SCREW, 1/4-20X1.25 HHC
312	601 00 23 18	NUT, 1/4-20 REGHEXCTRLK

318848C

CULTIVATOR PARTS CT20


TINE SHIELD ASSEMBLY



REF. NO.	PART NO.	PART NAME
480	601 00 12 86	SHIELD, TINE
481	601 00 12 87	SCREW, 1/4-20X5.00 HHC
482	601 00 00 18	WASHER, FLAT .281X .63X.065
483	601 00 23 18	NUT, 1/4-20 REGHEXCTRLK
490	601 00 06 02	WASHER, FELT.68X1.46X.12 WOOL
491	601 00 07 45	TINE, ASSY INNER LH
492	601 00 07 43	TINE, ASSY OUTER LH
493	601 00 07 44	TINE, ASSY INNER RH
494	601 00 07 42	TINE, ASSY OUTER RH
495	601 00 05 99	PIN, CLEVIS .31X1.38
496	601 00 06 04	PIN, HAIR .53DIAX1.62LG

318849D

**CULTIVATOR PARTS CT20
WHEEL ASSEMBLY**




REF. NO.	PART NO.	PART NAME
650	601 00 12 88	WHEEL SUPT,ASSY
660	601 00 18 60	PIN, CLEVIS .321X.75BR
661	601 00 06 04	PIN, HAIR .53DIA X 1.62LG
662	601 00 22 57	TIRE & RIM,SEPU 5.0 X 1.(696)
663	601 00 12 91	NUT, PUSH ON 3/8"

318852F

CULTIVATOR PARTS CT20

REMOTE STOP ASSEMBLY




REF. NO.	PART NO.	PART NAME
950	601 00 22 58	SWITCH ASSEMBLY
951	601 00 12 99	PLATE, INDICATOR
953	601 00 24 65	BRACKET, SWITCH
954	601 00 13 07	LOCKWASHER
955	601 00 13 04	SWITCH
956	601 00 24 66	BRACKET, SWITCH
957	601 00 22 59	DÉCAL, ON-OFF
980	601 00 22 60	KILL SWITCH ASSEMBLY
990	601 00 06 28	TIE CABLE

341421C

CULTIVATOR PARTS CT20


DECALS



REF. NO.	PART NO.	PART NAME
822	-	REFERENCE ONLY
823	601 00 12 96	DECAL, CAUTION
824	601 00 20 96	DECAL, HUSQVARNA TOP COVER
825	601 00 22 00	DECAL, RECOIL HSING HUSQV.
826	601 00 11 95	DECAL, HOLD RH GRIP
830	601 00 24 67	DECAL, TINE SHIELD CT-20 HUSQV

339945B

**CULTIVATOR PARTS CT20
HANDLE ASSEMBLY**



REF. NO.	PART NO.	PART NAME
930	601 00 22 62	HANDLE, UPPER .75X18GASTEEL
932	601 00 22 63	HANDLE, LOWER LH
934	601 00 22 64	HANDLE, LOWER RH
941	601 00 12 94	BOLT, 5/16-18X1.63 CARRSP
942	601 00 23 12	WASHER,.343IDX1.0X.062 FORM
943	601 00 00 19	WASHER, FLAT .344X .69X.065
944	601 00 06 84	KNOB, T 2BLADE W/516-18 NUT
945	601 00 00 12	NUT, 5/16-18 REGHEX
946	601 00 06 18	GRIP, HAND
947	601 00 12 15	SCREW, 10-16X1.50 WAHHTAP
948	601 00 06 28	TIE, CABLE BLACK NYLON 5.62L

319375C