



Parts List for CT224-B3 Type 1

| Item Number | Part Number | Description | Qty Required |
|-------------|-------------|------------------|--------------|
| 1 | 5140096-10 | TANK ASSEMBLY | 1 |
| 2 | 5140096-11 | NUT | 10 |
| 3 | 5140096-12 | SPRING WASHER | 11 |
| 4 | 5140096-13 | FLAT WASHER | 16 |
| 5 | 5140096-14 | WHEEL ASSY. | 2 |
| 6 | 5140096-15 | SCREW | 2 |
| 7 | 5140096-16 | PLUG | 2 |
| 8 | 5140096-17 | TUBE ASSY | 1 |
| 9 | 5140096-18 | SPRING WASHER | 4 |
| 10 | 5140096-19 | CLAPBOARD | 2 |
| 11 | 5140096-20 | FRONT HOUSING | 1 |
| 12 | 5140096-21 | FAN | 1 |
| 13 | 5140096-22 | REAR MOTOR COVER | 1 |
| 14 | 5140096-23 | WAVY WASHER | 1 |
| 15 | 5140096-24 | BEARING | 1 |
| 16 | 5140096-25 | SCREW | 4 |
| 17 | 5140098-30 | STATOR ASSY. | 1 |
| 18 | 5140096-27 | ROTOR ASSY. | 1 |
| 19 | 5140098-31 | CAPACITOR | 1 |
| 20 | 5140096-29 | WASHER | 1 |
| 21 | 5140096-30 | SCREW | 4 |
| 22 | 5140096-31 | BEARING | 1 |
| 23 | 5140096-32 | LIP SEAL | 1 |
| 24 | 5140096-33 | BOLT | 1 |
| 25 | 5140096-34 | CRANK CASE | 1 |
| 26 | 5140096-35 | CRANK | 1 |
| 27 | 5140096-36 | SCREW | 1 |

Parts List for CT224-B3 Type 1

| Item Number | Part Number | Description | Qty Required |
|-------------|-------------|----------------------|--------------|
| 28 | 5140096-37 | CRANKCASE GASKET | 1 |
| 29 | 5140096-38 | BREATHER ASSY. | 1 |
| 30 | 5140096-39 | CRANKCASE COVER | 1 |
| 31 | 5140096-40 | OIL LEVELER | 1 |
| 32 | 5140096-30 | SCREW | 6 |
| 33 | 5140096-42 | HANDLE | 1 |
| 34 | 5140096-43 | CYLINDER GASKET | 1 |
| 35 | 5140096-44 | CONNECTING ROD | 1 |
| 36 | 5140096-45 | PISTON | 1 |
| 37 | 5140096-46 | OIL RING | 1 |
| 38 | 5140096-47 | SEAL RING | 2 |
| 39 | 5140096-48 | CYLINDER | 1 |
| 40 | 5140096-49 | GASKET VALVE PLATE | 1 |
| 41 | 5140096-50 | ELBOW | 1 |
| 42 | 5140096-51 | SCREW | 4 |
| 43 | 5140096-52 | AIR FILTER ASSY. | 1 |
| 44 | 5140096-53 | CYLINDER HEAD | 1 |
| 45 | 5140096-54 | CYLINDER GASKET | 1 |
| 46 | 5140096-55 | VALVE PLATE ASSEMBLY | 1 |
| 47 | 5140096-56 | LOCATING PIN | 1 |
| 48 | 5140096-57 | VALVE AIR | 1 |
| 49 | 5140096-58 | CIRCLIP | 1 |
| 50 | 5140096-59 | PISTON PIN | 1 |
| 51 | 5140096-60 | LOCKING NUT | 1 |
| 52 | 5140096-61 | SAFETY VALVE | 1 |
| 53 | 5140096-62 | PRESSURE SWITCH | 1 |
| 54 | 5140096-63 | CONNECTOR | 1 |

Parts List for CT224-B3 Type 1

| Item Number | Part Number | Description | Qty Required |
|-------------|-------------|----------------|--------------|
| 55 | 5140096-64 | REGULATOR | 1 |
| 56 | 5140096-65 | VALVE ASSY | 1 |
| 57 | 5140096-66 | PRESSURE GAUGE | 1 |
| 58 | 5140096-67 | PRESSURE GAUGE | 1 |
| 59 | 5140096-68 | BOLT | 4 |
| 60 | 5140096-69 | DISCHARGE TUBE | 1 |
| 61 | 5140096-70 | CHECK VALVE | 1 |
| 62 | 5140098-32 | CORD SET | 1 |
| 63 | 5140096-72 | DRAIN VALVE | 1 |
| 64 | 5140096-73 | FOOT SUPPORT | 1 |
| 65 | 5140096-74 | FLAT WASHER | 1 |
| 66 | 5140096-75 | BOLT | 1 |
| 67 | 5140096-76 | CIRCLIP | 1 |
| 68 | 5140096-77 | FLAT WASHER | 2 |
| 69 | 5140096-30 | SCREW | 2 |
| 70 | 5140096-79 | SCREW | 2 |
| 71 | 5140096-80 | SCREW | 9 |
| 72 | 5140096-81 | REAR HOUSING | 1 |
| 73 | 5140096-82 | BOARD | 1 |
| 74 | 5140096-83 | O-RING | 1 |