







## Parts List for D21620K-B3 Type 1

Item Number	Part Number	Description	Qty Required
1	596930-00	ELECTRO MAGNET	1
2	596931-00	HOUSING	1
3	5140090-52	COVER PLATE	1
4	596935-00	GUIDE	2
5	596936-00	GLIDE STRIP	1
6	596937-00	PLATE	1
7	596938-00	SLIDER	1
8	596939-00	SUPPORT BRACKET	1
9	596940-00	RACK	1
10	596941-00	SCREW	2
11	596942-00	BUSH	2
12	596943-00	PINION	1
13	596944-00	SCREW	8
14	596945-00	HUB	1
15	596946-00	BALL	1
16	596947-00	PUSH ROD	1
17	596948-00	LOCK KNOB	1
18	596949-00	COMPRESSION SPRING	1
19	596950-00	HANDLE	3
20	596951-00	END CAP	1
21	596952-00	TANK	1
22	596953-00	INSERT	1
23	596954-00	CLIP	1
24	1004016-00	BRACKET ASSY	1
25	596956-00	GRUB SCREW	7
26	596957-00	INSERT	1
27	596958-00	GLAND	1

## Parts List for D21620K-B3 Type 1

Item Number	Part Number	Description	Qty Required
28	596959-00	SCREW	6
29	596960-00	THUMBSCREW	1
30	596961-00	BRAND LABEL	2
31	596962-00	LABEL	1
32	5140090-53	CABLE & PLUG	1
33	596966-00	SCREW	1
34	596967-00	TUBE	1
35	596968-00	PIN, SPIROL	2
36	597020-00	STRAP	1
37	596971-00	SHIM	1
38	596972-00	BEARING BUSH	1
39	596973-00	SEAL	1
40	596974-00	SEAL	1
41	596975-00	GLAND	1
42	596976-00	GUARD	1
43	596977-00	THUMBSCREW	3
46	597007-00	NUT	2
47	597008-00	SCREW	4
48	597009-00	SPRING WASHER	4
49	596934-00	SLEEVE	1
50	596978-00	SUPPORT PLATE	1
51	596989-00	PCB	1
52	596990-00	HEATSINK	3
53	596991-00	SCREW	3
54	596992-00	BUSH	3
55	596993-00	WASHER	3
56	596994-00	NUT	3

## Parts List for D21620K-B3 Type 1

Item Number	Part Number	Description	Qty Required
57	596995-00	SUPPORT	3
58	596996-00	NUT	3
59	596997-00	SCREW	3
60	596998-00	SWITCH	1
61	596999-00	SWITCH	1
62	597000-00	GROMMET	3
63	597001-00	NEON	1
65	597003-00	SUPPRESSOR	1
66	597004-00	SWITCH	1
67	597005-00	COVER PLATE	1
70	1002874-00	KIT	1
101	596818-00	BRUSH COVER	1
102	596819-00	SCREW	4
103	596820-00	ARMATURE	1
104	596822-00	BEARING	2
105	596823-00	CLIP	1
106	596824-00	BRUSH HOLDER	2
107	596825-00	BRUSH PAIR KIT	1
108	596826-00	WASHER	4
109	596827-00	SCREW	4
110	596828-00	CONTACT PLATE	2
111	596829-00	CIRCLIP	1
112	596830-00	O RING	1
113	596831-00	SCREW	4
114	596832-00	BEARING	1
115	596833-00	GEAR CASE COVER	1
116	596834-00	GEARCASE	1

## Parts List for D21620K-B3 Type 1

Item Number	Part Number	Description	Qty Required
117	596835-00	GEAR	1
118	596836-00	INTERSHAFT	1
119	596837-00	CHANGE LEVER	1
120	596838-00	LEVER	1
121	596839-00	PIN	1
122	596840-00	BEARING	2
123	596841-00	SPINDLE	1
124	596842-00	KEY	1
125	596843-00	PROTECTOR	1
126	596844-00	CABLE	1
128	596845-00	GASKET	1
129	596846-00	COVER PLATE	1
132	596847-00	GEAR	1
134	596848-00	SHIM	1
135	596849-00	CIRCLIP	1
136	596850-00	SHAFT	1
138	596851-00	GEAR ASSY.	1
139	596852-00	KEY	1
140	596853-00	NEEDLE BEARING	3
142	596854-00	FAN BAFFLE	1
143	596855-00	SCREW	2
144	596856-00	FIELD	1
145	596858-00	MOTOR HOUSING	1
146	596859-00	SUPPRESSOR	1
147	596860-00	SLEEVE	1
521	596978-00	SUPPORT PLATE	1
522	596979-00	COLLAR	1

## Parts List for D21620K-B3 Type 1

Item Number	Part Number	Description	Qty Required
523	596980-00	O RING	1
524	596981-00	CIRCLIP	1
525	596982-00	SPRING	2
526	596983-00	COMPRESSION SPRING	1
527	596984-00	LOCING DEVICE	1
528	596985-00	COMPRESSION SPRING	1
529	596986-00	PLUG	1
530	1004117-00	SPANNER SPECIAL	1
800	870889-02	GREASE	1