



Parts List for D24000 Type 1

Item Number	Part Number	Description	Qty Required
1	393073-16	NAMEPLATE	1
2	5140024-35	FIELD CASE	1
3	5140024-36	FIELD	1
4	5140024-37	ARMATURE & BRGS	1
5	605040-27	BALL BEARING	1
6	N043347	BALL BEARING	1
7	398605-00	RETAINING RING	1
10	618303-00	SCREW	5
12	609970-00	BEARING CUP	1
13	682149-00	BUSHING,STR.RLF	1
16	616755-00	ARBOR NUT	1
17	612689-00	CLAMP WASHER	1
18	612690-00	CLAMP WASHER	1
19	618302-11	SCREW	1
20	612692-00	GEAR CASE COVER ASSY.	1
21	330003-29	BALL BEARING	1
24	618302-03	SCREW	16
26	627524-00	ARM	1
27	618132-00	LABEL	1
28	330004-06	BEARING,NEEDLE	1
29	612698-00	SPINDLE LOCK	1
30	618568-00	FELT WIPER	1
31	398736-00	SPRING	2
32	616758-00	SPINDLE LOCK BUTTON	1
33	612701-00	LINER	1
34	618302-00	SCREW	4
35	612702-00	HANDLE	1

Parts List for D24000 Type 1

Item Number	Part Number	Description	Qty Required
36	618302-06	SCREW	17
37	624451-00	COVER	1
38	148608-01	INSERT	4
39	612704-00	SLEEVE	1
40	612705-00	RETAINER	1
41	612768-00	NOSE	1
42	612771-00	MANIFOLD	1
43	613462-00	NOZZLE	2
44	618353-00	O-RING	4
45	612773-00	PLATE	1
47	612774-00	LEVER	1
48	618303-02	SCREW	1
49	612728-00	RETAINER	1
50	618369-00	SHOULDER SCREW	11
51	612776-00	FLAPPER	1
52	618302-02	SCREW	18
53	618540-00	WASHER	12
54	612778-00	FLAPPER	1
55	618540-01	WASHER	1
56	618314-00	COVER	1
57	395021-00	LABEL	1
58	618136-00	CAUTION LABEL	1
59	618304-00	SCREW	1
61	612707-00	SPACER	1
62	618369-02	SHOULDER SCREW	1
63	618304-02	SCREW	1
64	612669-00	TRUNNION	1

Parts List for D24000 Type 1

Item Number	Part Number	Description	Qty Required
65	612708-00	PIVOT SHAFT	1
66	614031-00	PIVOT SHAFT	1
67	612710-00	SPACER	2
68	612711-00	SPRING	1
69	612709-00	BUSHING	4
70	618305-00	SET SCREW	4
71	612712-00	BEVEL KNOB	1
74	616763-00	KNOB	1
75	618305-02	SET SCREW	1
76	612671-00	BRACKET	1
77	618069-00	KNOB	1
78	618540-02	WASHER	2
79	623621-00	BOLT	1
80	612709-01	BUSHING	1
81	612717-00	PIN	1
82	618542-00	RETAINING RING	1
83	618305-01	SET SCREW	1
84	618313-00	COLUMN	1
85	618129-00	WARNING LABEL	1
86	612718-00	PLATE	1
87	616769-00	WRENCH	1
88	98000-13	HEX WRENCH	1
89	147190-01	CLIP	1
90	618123-00	CLIP	1
91	627525-00	SUPPORT ARM	1
92	616770-01	SHOULDER SCREW	3
93	616771-00	PLATE	1

Parts List for D24000 Type 1

Item Number	Part Number	Description	Qty Required
94	613811-00	PLATE	1
95	618133-00	LABEL	1
96	612722-00	COVER	1
97	612724-00	END CAP	1
98	618662-00	SWITCH	1
99	612784-00	SWITCH PLATE	1
100	612726-00	SWITCH BEZEL	1
101	612727-00	ENCLOSURE	1
102	618303-01	SCREW	28
103	616772-00	COVER	1
104	616773-00	ENCLOSURE	1
105	616774-00	CORD	1
106	450212-00	TERMINAL,MALE	4
107	450213-00	TERMINAL,FEMALE	6
109	605155-00	BUSHING	5
110	636714-00	CORD	1
110	618958-00	CORD	1
111	053650-03	TERMINAL	2
112	618605-00	CORD & PLUG	1
114	388301-00	WIRE CLIP	1
115	98102-10	SCREW,M4-U0	3
116	385865-00	SCREW	2
117	619683-00	CLAMP	4
118	612775-00	ELBOW	1
120	612673-00	FRAME	1
121	617634-00	PLATE	1
122	617635-00	PLATE	2

Parts List for D24000 Type 1

Item Number	Part Number	Description	Qty Required
123	618369-03	SHOULDER SCREW	4
124	618304-03	SCREW	2
129	616767-00	FOOT	4
131	612732-00	RAIL	1
132	617352-00	LINER	1
133	612777-00	CAP	1
134	612854-00	CAP	1
136	612733-00	GUIDE ROD	1
137	627522-00	BLOCK	4
138	613465-00	CYLINDER	1
139	612735-00	SCREW	1
140	618541-00	RETAINING RING	1
141	618304-01	SCREW	8
142	612737-00	RAIL	1
143	618302-07	SCREW	4
144	612738-00	BRACKET	2
146	612758-00	SCREW	2
147	399042-00	BUSHING	2
148	620468-00	SCREW	1
150	616770-00	SHOULDER SCREW	4
151	617948-00	CART	1
151	618312-00	CART	1
152	618130-00	WARNING LABEL	1
153	618131-00	LABEL	1
154	610707-00	WARNING LABEL	2
155	612741-00	ROLLER GUIDE	3
157	612743-00	SPACER	6

Parts List for D24000 Type 1

Item Number	Part Number	Description	Qty Required
158	330003-82	BALL BEARING	9
159	618304-07	SCREW	3
160	612745-00	SHAFT	3
161	618539-00	STOP NUT	6
162	612746-00	CYLINDER	1
164	612742-00	ROLLER	3
165	612748-00	SPACER	3
166	618304-05	SCREW	3
167	612749-00	PLATE	1
169	612752-00	SCALE	1
171	616784-00	BRACKET	1
172	617230-00	ROD	1
173	616785-00	SCREW	1
174	612755-00	BRUSH	1
175	612756-00	GUTTER	2
176	618369-01	SHOULDER SCREW	12
177	612757-00	DISC	1
179	612739-00	STOP	1
180	612759-00	COLLECTOR	1
181	612687-00	EDGE GUIDE	1
182	612761-00	GUIDE	1
184	612716-00	KNOB	2
185	612763-00	CLAMPING PLATE	1
187	618697-00	TUBING	1
188	631599-00	VALVE	1
189	612780-00	PUMP	1
190	616779-00	FITTING	1

Parts List for D24000 Type 1

Item Number	Part Number	Description	Qty Required
191	622978-00	PAN	1
192	612783-00	EXTENSION	1
193	612786-00	STOPPER	1
194	618076-00	TRAY	1
195	623509-00	BEVEL POINTER	1
196	153460-06	SCREW	1
197	618302-05	SCREW	4
198	13486-00	SCREW	2
199	613365-00	WING NUT	1
200	618305-06	SET SCREW	1
203	624434-00	COVER	1
204	618302-08	SCREW	2
205	624147-00	LEAD	1
206	624147-01	LEAD ASSY.	1
207	393520-00	TERMINAL BLOCK	1
209	623773-00	ROPE	1
210	622977-00	COVER	3
211	618302-01	SCREW	2
212	618320-00	EXTENSION	1
213	612753-00	SCALE	1
214	623075-00	GUIDE PIN	2
215	618539-01	NUT	2
216	623086-00	INSERT	1
217	623383-00	DISC	1
218	618302-09	SCREW	4
219	618540-03	WASHER	2
220	624727-00	PIN	1

Parts List for D24000 Type 1

Item Number	Part Number	Description	Qty Required
221	622976-00	LATCH	1
222	605365-00	RETAINING CLIP	1
223	618302-10	SCREW	1
226	56122-00	O-RING	1
227	618540-04	WASHER	3
229	625913-00	SPRING	1
230	609971-00	SLEEVE	1
231	625745-00	CORD CLIP	1
232	148608-02	INSERT	4
233	5140024-30	BRUSH	2
234	5140024-31	BRUSH HOLDER	2
235	614368-00	BRUSH CAP	2
236	5140024-33	SET SCREW	2
237	5140024-34	SCREW	2
238	627857-00	ROLLER	3
239	619840-00	SHIELD	1
251	612688-00	EDGE GUIDE	1
252	635225-00	GFCI PLUG	1
253	496555-00	SCREEN	1
254	5140058-96	GASKET	1
255	5140058-97	COVER	1
256	5140058-98	SCREW	3
800	790206-00	GREASE, 6 OZ.	1
856	DW4762	CUTTING WHEEL	1
856	DW4764	BLADE	1
856	DW4760	CUTTING WHEEL	1
856	DW4761	CUTTING WHEEL	1